

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
040-21101	WHEEL MAIN	CLEVELAND	AWBPC0001
040-23901	WHEEL MAIN	CLEVELAND	AWBPC0001
10-1063	HUB OUTBOARD	BF GOODRICH	32-40-
10-1064	HUB INBOARD	BF GOODRICH	32-40-
10-1069	HUB INBOARD	BF GOODRICH	3-1197 (266)
10-1070	HUB OUTBOARD	BF GOODRICH	3-1197 (266)
101-380096-1	BRAKE UNIT	BF GOODRICH	32-46-27
10-1419	HUB INBOARD	BF GOODRICH	ASTM-E-1417-M
10-1419-1	HUB INBOARD	BF GOODRICH	ASTM-E-1417-M
10-1419-2	HUB INBOARD	BF GOODRICH	ASTM-E-1417-M
10-1420	HUB OUTBOARD	BF GOODRICH	ASTM-E-1417-M
10-1420-1	HUB OUTBOARD	BF GOODRICH	ASTM-E-1417-M
10-1420-2	HUB OUTBOARD	BF GOODRICH	ASTM-E-1417-M
10-1457	HUB OUTBOARD	BF GOODRICH	32-41-20
10-1509	HUB OUTBOARD	BF GOODRICH	32-45-03
10-1509-1	HUB OUTBOARD	BF GOODRICH	32-45-03
10-1509-2	HUB OUTBOARD	BF GOODRICH	32-45-03
10-1510	HUB INBOARD	BF GOODRICH	32-45-03
10-1510-1	HUB INBOARD	BF GOODRICH	32-45-03
10-1510-2	HUB INBOARD	BF GOODRICH	32-45-03
10-1580	HUB INBOARD	BF GOODRICH	32-41-20
10-1583	HUB INBOARD	BF GOODRICH	32-41-13
10-1583-1	HUB INBOARD	BF GOODRICH	32-41-13
10-1584	HUB OUTBOARD	BF GOODRICH	32-41-13
10-1584-1	HUB OUTBOARD	BF GOODRICH	32-41-13
10-1590	HUB OUTBOARD	BF GOODRICH	32-41-20
10-1626	HUB OUTBOARD	BF GOODRICH	32-40-50
10-1634	HUB OUTBOARD	BF GOODRICH	32-45-47
10-1635	HUB INBOARD	BF GOODRICH	32-45-47
10-1684-3	HUB OUTBOARD	BF GOODRICH	32-49-11
10-1787	HUB OUTBOARD	BF GOODRICH	32-49-11
10-1792	HUB OUTBOARD	BF GOODRICH	32-40-50
101-8001-31	HUB INBOARD	BF GOODRICH	32-45-23
101-8001-45	HUB OUTBOARD	BF GOODRICH	32-45-23
101-8001-47	WHEEL MAIN	BF GOODRICH	32-45-23
101-8002-3	BRAKE UNIT	MEGGITT	32-44-09
101-8002-5	WHEEL MAIN	MEGGITT/ABS	32-40-47
101-8002-51	WHEEL MAIN	MEGGITT/ABS	32-40-47
101-8002-53	HUB OUTBOARD	MEGGITT/ABS	32-40-47
101-8002-55	HUB OUTBOARD	MEGGITT/ABS	32-40-47
101-8002-57	WHEEL MAIN	MEGGITT/ABS	32-40-47
101-8002-59	HUB OUTBOARD	MEGGITT/ABS	32-40-47
101-8002-61	HUB OUTBOARD	MEGGITT/ABS	32-40-47
101-8002-7	HUB OUTBOARD	MEGGITT/ABS	32-40-47
101-8002-9	HUB INBOARD	MEGGITT/ABS	32-40-47
101-8015-3	WHEEL NOSE	BEECHCRAFT	998-31258
101-8015-5	HUB INBOARD	BEECHCRAFT	998-31258
101-8015-7	HUB OUTBOARD	BEECHCRAFT	998-31258
101-8026-5	WHEEL NOSE	BEECHCRAFT	998-31258
101-8026-7	HUB OUTBOARD	BEECHCRAFT	998-31258
101-8026-9	HUB OUTBOARD	BEECHCRAFT	998-31258
10-62204-1	FUSE HYDRAULIC	TRIUMPH	32-40-11
10-62204-11	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
10-62204-12	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
10-62204-14	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
10-62204-15	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
10-62204-16	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
10-62204-24	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
10-62204-4	FUSE HYDRAULIC	TRIUMPH ACTUATION	32-40-12
10-62237-7	WHEEL MAIN	BF GOODRICH	32-40-50
114-388024-1	BRAKE UNIT	MEGGITT	32-44-66
114-388025-1	WHEEL MAIN	MEGGITT	Q82-01
114-8002-3	BRAKE UNIT	MEGGITT	Q82-02
114-8003-3	BRAKE UNIT	MEGGITT	Q82-02
114-8007-3	BRAKE UNIT	MEGGITT	Q82-02
114-8008-3	BRAKE UNIT	MEGGITT	Q82-02
115-8001-3	BRAKE UNIT	BF GOODRICH	998-31257
154251-1	WHEEL MAIN	PNEUDRAULICS	32-40-05
161-11600	HUB INBOARD	CLEVELAND	AWBCMM0001
161-12400	HUB INBOARD	CLEVELAND	AWBCMM0001
161-17301	HUB INBOARD	CLEVELAND	AWBCMM0001
161-19602	HUB INBOARD	CLEVELAND	CM40-412
161-19700	HUB INBOARD	CLEVELAND	CM40-413
161-20501	HUB INBOARD	CLEVELAND	CM40-424
161-22100	HUB INBOARD	CLEVELAND	CM40-412
162-10600	HUB OUTBOARD	CLEVELAND	AWBCMM0001
162-11400	HUB OUTBOARD	CLEVELAND	AWBCMM0001
162-17301	HUB OUTBOARD	CLEVELAND	AWBCMM0001
162-17302	HUB OUTBOARD	CLEVELAND	AWBCMM0001
162-19602	HUB OUTBOARD	CLEVELAND	CM40-412
162-19700	HUB OUTBOARD	CLEVELAND	CM40-413
162-20501	HUB OUTBOARD	CLEVELAND	CM40-424
200SGL1103-3	DRIVESHAFT	AMS	ASTM-E-1444
200SGL1103-9	DRIVESHAFT	AMS	ASTM-E-1444
2-1147	BRAKE UNIT	BF GOODRICH	32-40-18
2-1147-1	BRAKE UNIT	BF GOODRICH	32-40-18
2-1147-3	BRAKE UNIT	BF GOODRICH	32-40-18
2-1147-4	BRAKE UNIT	BF GOODRICH	32-40-18
2-1203	BRAKE UNIT	BF GOODRICH	32-46-78
2-1203-1	BRAKE UNIT	BF GOODRICH	32-46-78
2-1203-2	BRAKE UNIT	BF GOODRICH	32-46-78
2-1203-3	BRAKE UNIT	BF GOODRICH	32-46-78
2-1203-4	BRAKE UNIT	BF GOODRICH	32-46-78
2-1457	BRAKE UNIT	BF GOODRICH	32-40-26
2-1457-1	BRAKE UNIT	BF GOODRICH	32-40-26
2-1457-2	BRAKE UNIT	BF GOODRICH	32-40-26
2-1466-3	BRAKE UNIT	BF GOODRICH	32-42-17
2-1466-4	BRAKE UNIT	BF GOODRICH	32-42-17
2-1466-5	BRAKE UNIT	BF GOODRICH	32-42-17
2-1474-5	BRAKE UNIT	BF GOODRICH	32-40-30
2-1474-7	BRAKE UNIT	BF GOODRICH	32-40-30
2-1510	BRAKE UNIT	BF GOODRICH	32-46-01
2-1515-1	BRAKE UNIT	BF GOODRICH	32-46-02
2-1515-2	BRAKE UNIT	BF GOODRICH	32-46-02
2-1517	BRAKE UNIT	BF GOODRICH	32-46-70
2-1517-1	BRAKE UNIT	BF GOODRICH	32-46-70
2-1521	BRAKE UNIT	BF GOODRICH	32-46-03
2-1521-1	BRAKE UNIT	BF GOODRICH	32-46-03
2-1522-1	BRAKE UNIT	BF GOODRICH	32-46-72
2-1528-4	BRAKE UNIT	BF GOODRICH	32-46-42
2-1528-5	BRAKE UNIT	BF GOODRICH	32-46-42
2-1528-6	BRAKE UNIT	BF GOODRICH	32-46-42
2-1545-4	BRAKE UNIT	BF GOODRICH	32-41-80
2-1545-5	BRAKE UNIT	BF GOODRICH	32-41-80
2-1545-7	BRAKE UNIT	BF GOODRICH	32-41-80
2-1545-8	BRAKE UNIT	BF GOODRICH	32-41-80

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
2-1549-2	BRAKE UNIT	BF GOODRICH	32-46-86
2-1549-3	BRAKE UNIT	BF GOODRICH	32-46-86
2-1565	BRAKE UNIT	BF GOODRICH	32-46-88
2-1566OPT1	BRAKE UNIT	BF GOODRICH	32-40-43
2-1566OPT2	BRAKE UNIT	BF GOODRICH	32-40-43
2-1572	BRAKE UNIT	BF GOODRICH	32-41-63
2-1574	BRAKE UNIT	BF GOODRICH	32-46-26
2-1576	BRAKE UNIT	BF GOODRICH	32-46-27
2-1577-1	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-1OPT1	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-1OPT2	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-3	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-4	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-5	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-6	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-7	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-8	BRAKE UNIT	BF GOODRICH	32-41-81
2-1577-9	BRAKE UNIT	BF GOODRICH	32-41-81
2-1578-1	BRAKE UNIT	BF GOODRICH	32-41-82
2-1578-2	BRAKE UNIT	BF GOODRICH	32-41-82
2-1578-3	BRAKE UNIT	BF GOODRICH	32-41-82
2-1578-4	BRAKE UNIT	BF GOODRICH	32-41-82
2-1578-5	BRAKE UNIT	BF GOODRICH	32-41-82
2-1578-6	BRAKE UNIT	BF GOODRICH	32-41-82
2-1582	BRAKE UNIT	BF GOODRICH	32-49-01
2-1586	BRAKE UNIT	BF GOODRICH	32-40-47
2-1586-1	BRAKE UNIT	BF GOODRICH	32-40-47
2-1587-1	BRAKE UNIT	BF GOODRICH	32-40-48
2-1588	BRAKE UNIT	BF GOODRICH	32-46-48
2-1588-1	BRAKE UNIT	BF GOODRICH	32-46-48
2-1599	BRAKE UNIT	BF GOODRICH	32-48-31
2-1600	BRAKE UNIT	BF GOODRICH	32-41-79
2-1600-1	BRAKE UNIT	BF GOODRICH	32-41-79
2-1600-2	BRAKE UNIT	BF GOODRICH	32-41-79
2-1600-3	BRAKE UNIT	BF GOODRICH	32-41-79
2-1605	BRAKE UNIT	BF GOODRICH	32-48-33
2-1605-1	BRAKE UNIT	BF GOODRICH	32-48-33
2-1605-2	BRAKE UNIT	BF GOODRICH	32-48-33
2-1624	BRAKE UNIT	BF GOODRICH	
2-1624OPT2	BRAKE UNIT	BF GOODRICH	
2-1684	BRAKE UNIT	BF GOODRICH	32-41-87
2-1693	BRAKE UNIT	BF GOODRICH	32-40-57
2-1693-1	BRAKE UNIT	BF GOODRICH	32-40-57
2-1699-1	BRAKE UNIT	BF GOODRICH	32-49-10
2-1699-2	BRAKE UNIT	BF GOODRICH	32-49-10
2-1699-3	BRAKE UNIT	BF GOODRICH	32-49-10
2-1706-1	BRAKE UNIT	BF GOODRICH	32-46-77
2-1707	BRAKE UNIT	BF GOODRICH	32-49-12
2-1707-1	BRAKE UNIT	BF GOODRICH	32-49-12
2-1707-2	BRAKE UNIT	BF GOODRICH	32-49-12
2-1711	BRAKE UNIT	BF GOODRICH	32-44-01
2-1727	BRAKE UNIT	BF GOODRICH	32-44-27
23032-1692	DRIVESHAFT	AMS	ASTM-E-1444
23032-1900	HUB DAMPENER	AMS	ASTM-E-1444
23032-1901	HUB DAMPENER	AMS	ASTM-E-1444
23032-2844	DRIVESHAFT	AMS	ASTM-E-1444
23046-1121	SHAFT	AMS	ASTM-E-1444
23046-1125	SHAFT	AMS	ASTM-E-1444

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
23046-1129	SHAFT	AMS	ASTM-E-1444
23046-2153	SHAFT	AMS	ASTM-E-1444
23085-1352	DRIVESHAFT	AMS	ASTM-E-1444
2601042-3	BRAKE UNIT	HONEYWELL	32-40-03
2601042-4	BRAKE UNIT	HONEYWELL	32-40-03
2601042-5	BRAKE UNIT	HONEYWELL	32-40-03
2601045-2	WHEEL NOSE	HONEYWELL	32-44-63
2601045-3	WHEEL NOSE	HONEYWELL	32-44-63
2601181-1	WHEEL MAIN	HONEYWELL	32-40-01
2601182-5	BRAKE UNIT	HONEYWELL	32-40-02
2601182-6	BRAKE UNIT	HONEYWELL	32-40-02
2601411-1	WHEEL MAIN	HONEYWELL	32-40-07
2601411-2	WHEEL MAIN	HONEYWELL	32-40-07
2601412-1	BRAKE UNIT	HONEYWELL	32-40-08
2601412-2	BRAKE UNIT	HONEYWELL	32-40-08
2601450	HUB INBOARD	HONEYWELL	32-40-01
2601454	HUB OUTBOARD	HONEYWELL	32-40-01
2601571-1	WHEEL MAIN	HONEYWELL	32-40-01
2601901-1	WHEEL MAIN	HONEYWELL	32-45-10
2601901-2	WHEEL MAIN	HONEYWELL	32-45-10
2601901-4	WHEEL MAIN	HONEYWELL	32-45-10
2601901-5	WHEEL MAIN	HONEYWELL	32-45-10
2601901-6	WHEEL MAIN	HONEYWELL	32-45-10
2601901-7	WHEEL MAIN	HONEYWELL	32-45-10
2601902-1	BRAKE UNIT	HONEYWELL	32-41-30
2601902-2	BRAKE UNIT	HONEYWELL	32-41-30
2601902-3	BRAKE UNIT	HONEYWELL	32-41-30
2601902-30	BRAKE UNIT	HONEYWELL	32-41-30
2601902-4	BRAKE UNIT	HONEYWELL	32-41-30
2601902-40	BRAKE UNIT	HONEYWELL	32-41-30
2601902-5	BRAKE UNIT	HONEYWELL	32-41-30
2601902-50	BRAKE UNIT	HONEYWELL	32-41-30
2601902-6	BRAKE UNIT	HONEYWELL	32-41-30
2601902-60	BRAKE UNIT	HONEYWELL	32-41-30
2602012-30	BRAKE UNIT	HONEYWELL	32-41-30
2602012-40	BRAKE UNIT	HONEYWELL	32-41-30
2602012-50	BRAKE UNIT	HONEYWELL	32-41-30
2603044-1	HUB INBOARD	HONEYWELL	32-44-63
2603045	HUB INBOARD	HONEYWELL	32-44-63
2603046-1	HUB INBOARD	HONEYWELL	32-44-63
2603561-50	WHEEL MAIN	HONEYWELL	32-45-01
2603561-51	WHEEL MAIN	HONEYWELL	32-45-01
2603561-52	WHEEL MAIN	HONEYWELL	32-45-01
2604561-1	WHEEL MAIN	HONEYWELL	32-40-03
2605392-1	BRAKE UNIT	HONEYWELL	32-41-31
2605662-1	BRAKE UNIT	HONEYWELL	32-45-17
2605662-2	BRAKE UNIT	HONEYWELL	32-45-17
2605662-20	BRAKE UNIT	HONEYWELL	32-45-17
2605662-3	BRAKE UNIT	HONEYWELL	32-45-17
2606671-1	WHEEL MAIN	HONEYWELL	32-40-09
2606671-2	WHEEL MAIN	HONEYWELL	32-40-09
2606671-3	WHEEL MAIN	HONEYWELL	32-40-09
2606671-4	WHEEL MAIN	HONEYWELL	32-40-09
2606672-1	BRAKE UNIT	HONEYWELL	32-40-08
2606672-2	BRAKE UNIT	HONEYWELL	32-40-08
2606672-3	BRAKE UNIT	HONEYWELL	32-40-08
2606672-4	BRAKE UNIT	HONEYWELL	32-40-08
2606685	HUB INBOARD	HONEYWELL	32-40-09

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
2606685-1	HUB INBOARD	HONEYWELL	32-40-09
2606692	HUB OUTBOARD	HONEYWELL	32-40-09
2606697	HOUSING PISTON	HONEYWELL	32-40-08
2606706	TUBE TORQUE	HONEYWELL	32-40-08
2606735-1	WHEEL NOSE	HONEYWELL	32-43-01
2606735-2	WHEEL NOSE	HONEYWELL	32-43-01
2606798	HUB OUTBOARD	HONEYWELL	32-42-06
2606801-1	WHEEL MAIN	HONEYWELL	32-42-06
2606801-2	WHEEL MAIN	HONEYWELL	32-42-06
2606801-3	WHEEL MAIN	HONEYWELL	32-42-06
2606801-4	WHEEL MAIN	HONEYWELL	32-42-06
2606802-3	BRAKE UNIT	HONEYWELL	32-42-02
2606802-5	BRAKE UNIT	HONEYWELL	32-42-02
2607046-1	HUB INBOARD	HONEYWELL	32-40-01
2607047-1	HUB OUTBOARD	HONEYWELL	32-40-01
2607092-1	BRAKE UNIT	HONEYWELL	32-43-03
2607092-2	BRAKE UNIT	HONEYWELL	32-43-03
2607092-3	BRAKE UNIT	HONEYWELL	32-43-03
2607092-4	BRAKE UNIT	HONEYWELL	32-43-03
2607825-1	WHEEL NOSE	HONEYWELL	32-40-10
2607825-2	WHEEL NOSE	HONEYWELL	32-40-10
2607933-1	HUB INBOARD	HONEYWELL	32-42-06
2607941	TUBE TORQUE	HONEYWELL	32-40-08
2607948-1	HUB INBOARD	HONEYWELL	32-40-09
2607949-1	HUB OUTBOARD	HONEYWELL	32-40-09
2608023-1	HUB INBOARD	HONEYWELL	32-40-10
2608024-1	HUB OUTBOARD	HONEYWELL	32-40-10
2608058	HUB OUTBOARD	HONEYWELL	32-40-09
2608141	HUB OUTBOARD	HONEYWELL	32-42-06
2608245	HUB INBOARD	HONEYWELL	32-40-09
2608245-1	HUB INBOARD	HONEYWELL	32-40-09
2608769	HUB INBOARD	HONEYWELL	32-40-10
2608770	HUB OUTBOARD	HONEYWELL	32-40-10
260-880-1	HOUSING PISTON ASSY	BF GOODRICH	32-40-43
2608811-3	WHEEL MAIN	HONEYWELL	32-43-04
2608811-5	WHEEL MAIN	HONEYWELL	32-43-04
2608812-10	BRAKE UNIT	HONEYWELL	32-43-13
2608812-11	BRAKE UNIT	HONEYWELL	32-43-13
2608812-6	BRAKE UNIT	HONEYWELL	32-43-13
2608812-7	BRAKE UNIT	HONEYWELL	32-43-13
2608840	HUB INBOARD	HONEYWELL	32-42-06
2608892-1	BRAKE UNIT	HONEYWELL	32-44-02
2608910-1	HUB INBOARD	HONEYWELL	32-43-04
2608910-2	HUB INBOARD	HONEYWELL	32-43-04
2608912-1	HUB OUTBOARD	HONEYWELL	32-43-04
2608912-2	HUB OUTBOARD	HONEYWELL	32-43-04
2608978-1	TUBE TORQUE	HONEYWELL	32-40-08
2608981	BRAKE HOUSING	HONEYWELL	32-40-08
2609455-1	HOUSING PISTON	HONEYWELL	32-40-08
2609471-2	WHEEL MAIN	HONEYWELL	32-44-05
2609471-3	WHEEL MAIN	HONEYWELL	32-44-05
2609472-4	BRAKE UNIT	HONEYWELL	32-44-08
2609493-1	HUB INBOARD	HONEYWELL	32-43-04
2609493-2	HUB INBOARD	HONEYWELL	32-43-04
2609498-1	HUB OUTBOARD	HONEYWELL	32-43-04
2609498-2	HUB OUTBOARD	HONEYWELL	32-43-04
2609726-1	HUB INBOARD	HONEYWELL	32-44-05
2609728-1	HUB OUTBOARD	HONEYWELL	32-44-05

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
2609801-1	WHEEL MAIN	HONEYWELL	32-40-11
2609932-1	HUB INBOARD	HONEYWELL	32-40-11
2609932-1	HUB INBOARD	HONEYWELL	32-40-11
2609933-1	OUTBOARD HUB	HONEYWELL	32-40-11
2609933-1	OUTBOARD HUB	HONEYWELL	32-40-11
2610181-2	WHEEL MAIN	HONEYWELL	32-41-11
2610181-3	WHEEL MAIN	HONEYWELL	32-41-11
2610181-4	WHEEL MAIN	HONEYWELL	32-41-11
2610181-5	WHEEL MAIN	HONEYWELL	32-41-11
2610181-6	WHEEL MAIN	HONEYWELL	32-41-11
2610701-2	WHEEL MAIN	MEGGITT	32-41-34
2610702-2	BRAKE UNIT	HONEYWELL	32-46-01
2610702-3	BRAKE UNIT	HONEYWELL	32-46-01
2610702-3	BRAKE UNIT	MEGGITT	32-44-26
2610706-1	HUB INBOARD	MEGGITT	32-41-34
2610707-1	HUB OUTBOARD	MEGGITT	32-41-34
2611202-2	BRAKE UNIT	HONEYWELL	32-47-04
2611205-2	WHEEL NOSE	HONEYWELL	32-47-06
2611514-1	HOUSING PISTON	HONEYWELL	32-40-08
2611811-1	WHEEL MAIN	HONEYWELL	32-47-05
2612152-1	BRAKE UNIT	HONEYWELL	32-42-28
2612152-2	BRAKE UNIT	HONEYWELL	32-42-28
2612152-3	BRAKE UNIT	HONEYWELL	32-42-28
2612152-4	BRAKE UNIT	HONEYWELL	32-42-28
2612185-1	HUB INBOARD	HONEYWELL	32-47-05
2612188-1	HUB OUTBOARD	HONEYWELL	32-47-05
2612201-2	WHEEL MAIN	HONEYWELL	32-41-12
2612201-3	WHEEL MAIN	HONEYWELL	32-41-12
2612202-1	BRAKE UNIT	HONEYWELL	32-42-28
2612202-2	BRAKE UNIT	HONEYWELL	32-42-28
2612202-3	BRAKE UNIT	HONEYWELL	32-42-28
2612202-4	BRAKE UNIT	HONEYWELL	32-42-28
2612301-2	WHEEL MAIN	HONEYWELL	32-40-12
2612302-1	BRAKE UNIT	HONEYWELL	32-40-13
2612311-1	WHEEL MAIN	HONEYWELL	32-40-14
2612312-1	BRAKE UNIT	HONEYWELL	32-40-15
2612412-1	BRAKE UNIT	HONEYWELL	32-43-12
2612412-1A	BRAKE UNIT	HONEYWELL	32-43-12
2612462	HUB INBOARD	HONEYWELL	32-40-14
2612462-1	HUB INBOARD	HONEYWELL	32-40-14
2612622-1	HOUSING	HONEYWELL	32-43-12
2612769-1	HOUSING	HONEYWELL	32-43-12
2612798-1	HUB OUTBOARD	HONEYWELL	32-40-10
2612799-1	HUB INBOARD	HONEYWELL	32-40-10
2613023	HEATPACK	HONEYWELL	32-43-12
2613042-2	BRAKE UNIT	HONEYWELL	32-44-10
2613128-1	HUB OUTBOARD	HONEYWELL	32-40-14
2613166-1	TUBE TORQUE	HONEYWELL	32-43-12
2614997	HEATPACK	HONEYWELL	32-43-12
2615001-1	WHEEL MAIN	HONEYWELL	32-40-16
2615069	HEATPACK	HONEYWELL	32-43-12
2615480	HUB INBOARD	HONEYWELL	32-40-14
2615480-1	HUB INBOARD	HONEYWELL	32-40-14
2616738	HEATPACK	HONEYWELL	32-43-12
2616739	HEATPACK	HONEYWELL	32-43-12
2616782-1	HUB OUTBOARD	HONEYWELL	32-40-16
2616849-1	HUB INBOARD	HONEYWELL	32-40-16
2616931	HEATPACK CARBON	HONEYWELL	32-43-12

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
2616933	HEATPACK	HONEYWELL	32-43-12
266-235-1	HOUSING PISTON ASSY	BF GOODRICH	32-46-42
2-7462	VALVE SHUTTLE	TRIUMPH	32-42-03
2-7462-3	FUSE HYDRAULIC	MEGGITT	32-42-03
2-7680	FUSE HYDRAULIC	TRIUMPH	27-32-02
2-7680-1	FUSE HYDRAULIC	TRIUMPH	27-32-02
2-7680-2	FUSE HYDRAULIC	TRIUMPH	27-32-02
2-7681	FUSE HYDRAULIC	TRIUMPH	27-32-03
2-7681-1	FUSE HYDRAULIC	TRIUMPH	27-32-03
2-7681-2	FUSE HYDRAULIC	TRIUMPH	27-32-03
2-7729-1	FUSE HYDRAULIC	TRIUMPH	32-40-11
2-7734-1	FUSE HYDRAULIC	TRIUMPH ACTUATION	32-40-12
2-7735-1	FUSE HYDRAULIC	TRIUMPH	32-40-13
2-7737-1	FUSE HYDRAULIC	GE Aviation	32-40-15
277A6000-204	WHEEL MAIN	HONEYWELL	32-40-14
277A6000-451	WHEEL NOSE ASSY	HONEYWELL	32-40-10
2-8020	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-1	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-11	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-12	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-13	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-14	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-15	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-16	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-18	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-2	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-24	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-25	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-26	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-27	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-28	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-29	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-3	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-5	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8020-6	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
2-8041-1	FUSE HYDRAULIC	TRIUMPH	32-40-18
286254-1	HUB	SAFRAN	32-41-12
286254-2	HUB INBOARD	M Bugatti	32-41-12
286254-3	HUB	SAFRAN	32-41-12
286254AMDTC	HUB	SAFRAN	32-41-12
286255	HUB	M Bugatti	32-41-12
286255-1	HUB	M Bugatti	32-41-12
286255-2	HUB	M Bugatti	32-41-12
286255-3	HUB	M Bugatti	32-41-12
286255-4	HUB	SAFRAN	32-41-12
286351	WHEEL NOSE	HONEYWELL	32-41-12
286351001-1	WHEEL NOSE	HONEYWELL	32-41-12
286351001-2	WHEEL NOSE	HONEYWELL	32-41-12
286351002-1	WHEEL NOSE	HONEYWELL	32-41-12
286351002-2	WHEEL NOSE	HONEYWELL	32-41-12
286351003	WHEEL NOSE	HONEYWELL	32-41-12
286351003	WHEEL NOSE	M Bugatti	32-41-12
286351003-1	WHEEL NOSE	HONEYWELL	32-41-12
286351003-1	WHEEL NOSE	M Bugatti	32-41-12
286351003-100	WHEEL NOSE	HONEYWELL	32-41-12
286351003-101	WHEEL NOSE	HONEYWELL	32-41-12
286351003-102	WHEEL NOSE	HONEYWELL	32-41-12
286351003-103	WHEEL NOSE	HONEYWELL	32-41-12

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
286351003-2	WHEEL NOSE	HONEYWELL	32-41-12
286351003-2	WHEEL NOSE	M Bugatti	32-41-12
286351003-3	WHEEL NOSE	HONEYWELL	32-41-12
286351003-3	WHEEL NOSE	SAFRAN	32-41-12
286351-1	WHEEL NOSE	HONEYWELL	32-41-12
286351-2	WHEEL NOSE	HONEYWELL	32-41-12
2-872 SERIES	BRAKE UNIT	BF GOODRICH	32-40-4
2-873	BRAKE UNIT	BF GOODRICH	32-40-3
300-1012-1	HUB INBOARD	BF GOODRICH	32-44-03
300-1013-1	HUB OUTBOARD	BF GOODRICH	32-44-03
300-1029	HUB INBOARD	BF GOODRICH	32-44-70
300-1030	HUB OUTBOARD	BF GOODRICH	32-44-70
300-264	HUB OUTBOARD	BF GOODRICH	3-1197 (266)
300-265	HUB INBOARD	BF GOODRICH	3-1197 (266)
300-465-1	HUB OUTBOARD	BF GOODRICH	32-45-23
300-466	HUB INBOARD	BF GOODRICH	32-45-23
300-578	HUB INBOARD	BF GOODRICH	32-47-42
300-578OPT1	HUB INBOARD	BF GOODRICH	32-47-42
300-578OPT2	HUB INBOARD	BF GOODRICH	32-47-42
300-578OPT3	HUB INBOARD	BF GOODRICH	32-47-42
300-579	HUB OUTBOARD	BF GOODRICH	32-47-42
300-579OPT1	HUB OUTBOARD	BF GOODRICH	32-47-42
300-579OPT2	HUB OUTBOARD	BF GOODRICH	32-47-42
300-579OPT3	HUB OUTBOARD	BF GOODRICH	32-47-42
300-591	HUB OUTBOARD	BF GOODRICH	32-40-22
300-591-1	HUB OUTBOARD	BF GOODRICH	32-40-22
300-591OPT1	HUB OUTBOARD	BF GOODRICH	32-40-22
300-591OPT2	HUB OUTBOARD	BF GOODRICH	32-40-22
300-591OPT3	HUB OUTBOARD	BF GOODRICH	32-40-22
300-592	HUB INBOARD	BF GOODRICH	32-40-22
300-598	HUB INBOARD	BF GOODRICH	32-40-22
300-606	HUB INBOARD	BF GOODRICH	32-40-22
300-606OPT1	HUB INBOARD	BF GOODRICH	32-40-22
300-606OPT2	HUB INBOARD	BF GOODRICH	32-40-22
300-606OPT3	HUB INBOARD	BF GOODRICH	32-40-22
300-613	HUB INBOARD	BF GOODRICH	32-47-28
300-614	HUB OUTBOARD	BF GOODRICH	32-47-28
300-623	OUTBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-623-1OPT1	OUTBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-623-1OPT2	OUTBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-623-2OPT1	OUTBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-623-2OPT2	HUB OUTBOARD	BF GOODRICH	ASTM-E-1417-M
300-623OPT1	OUTBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-623OPT2	OUTBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-624	INBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-624-1OPT1	INBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-624-1OPT2	INBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-624-2OPT1	INBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-624-2OPT2	HUB INBOARD	BF GOODRICH	ASTM-E-1417-M
300-624OPT1	INBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-624OPT2	INBOARD HUB	BF GOODRICH	ASTM-E-1417-M
300-625-2	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-2OPT1	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-2OPT2	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-3	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-3OPT1	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-3OPT2	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-3OPT3	HUB OUTBOARD	BF GOODRICH	32-40-31

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
300-625-4	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-4OPT2	HUB OUTBOARD	BF GOODRICH	32-40-31
300-625-4OPT3	HUB OUTBOARD	BF GOODRICH	32-40-31
300-626-2	HUB INBOARD	BF GOODRICH	32-40-31
300-626-2OPT1	HUB INBOARD	BF GOODRICH	32-40-31
300-626-2OPT2	HUB INBOARD	BF GOODRICH	32-40-31
300-626-3	HUB INBOARD	BF GOODRICH	32-40-31
300-626-3OPT1	HUB INBOARD	BF GOODRICH	32-40-31
300-626-3OPT2	HUB INBOARD	BF GOODRICH	32-40-31
300-626-4	HUB INBOARD	BF GOODRICH	32-40-31
300-626-4OPT1	HUB INBOARD	BF GOODRICH	32-40-31
300-626-4OPT2	HUB INBOARD	BF GOODRICH	32-40-31
300-626-4OPT3	HUB INBOARD	BF GOODRICH	32-40-31
300-709	HUB OUTBOARD	BF GOODRICH	32-45-02
300-709-1	HUB OUTBOARD	BF GOODRICH	32-45-02
300-710	HUB INBOARD	BF GOODRICH	32-45-02
300-710-1	HUB INBOARD	BF GOODRICH	32-45-02
300-711	HUB INBOARD	BF GOODRICH	32-47-26
300-712	HUB OUTBOARD	BF GOODRICH	32-47-26
300-721	HUB OUTBOARD	BF GOODRICH	32-45-03
300-721-1	HUB OUTBOARD	BF GOODRICH	32-45-03
300-721-2	HUB OUTBOARD	BF GOODRICH	32-45-03
300-721-2OPT1	HUB OUTBOARD	BF GOODRICH	32-45-03
300-721-2OPT2	HUB OUTBOARD	BF GOODRICH	32-45-03
300-721-2OPT3	HUB OUTBOARD	BF GOODRICH	32-45-03
300-722	HUB INBOARD	BF GOODRICH	32-45-03
300-722-1	HUB INBOARD	BF GOODRICH	32-45-03
300-722-2	HUB INBOARD	BF GOODRICH	32-45-03
300-722-2OPT1	HUB INBOARD	BF GOODRICH	32-45-03
300-722-2OPT2	HUB INBOARD	BF GOODRICH	32-45-03
300-722-2OPT3	HUB INBOARD	BF GOODRICH	32-45-03
300-724-1	HUB INBOARD	BF GOODRICH	32-45-43
300-725-1	HUB OUTBOARD	BF GOODRICH	32-45-43
300-726	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT1	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT3	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT4	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726-2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726-2T1	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726-2T2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726-2T3	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726-2T4	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT1	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT3	HUB OUTBOARD	BF GOODRICH	32-41-20
300-726OPT4	HUB OUTBOARD	BF GOODRICH	32-41-20
300-776	HUB INBOARD	BF GOODRICH	32-45-02
300-776OPT1	HUB INBOARD	BF GOODRICH	32-45-02
300-776OPT2	HUB INBOARD	BF GOODRICH	32-45-02
300-776OPT3	HUB INBOARD	BF GOODRICH	32-45-02
300-796	HUB INBOARD	BF GOODRICH	32-41-20
300-796-1OPT1	HUB INBOARD	BF GOODRICH	32-41-20
300-796-1OPT2	HUB INBOARD	BF GOODRICH	32-41-20
300-796OPT1	HUB INBOARD	BF GOODRICH	32-41-20
300-796OPT2	HUB INBOARD	BF GOODRICH	32-41-20
300-799	HUB INBOARD	BF GOODRICH	32-41-13
300-799-1	HUB INBOARD	BF GOODRICH	32-41-13

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
300-799-1OPT1	HUB INBOARD	BF GOODRICH	32-41-13
300-799-1OPT2	HUB INBOARD	BF GOODRICH	32-41-13
300-799OPT1	HUB INBOARD	BF GOODRICH	32-41-13
300-799OPT2	HUB INBOARD	BF GOODRICH	32-41-13
300-800	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-1	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-1OPT1	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-1OPT2	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-1OPT3	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-1OPT4	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-2	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-2OPT1	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-2OPT2	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-2OPT3	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-2OPT4	HUB OUTBOARD	BF GOODRICH	32-41-13
300-800-3	HUB OUTBOARD	BF GOODRICH	32-41-13
300-805	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805-1OPT1	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805-1OPT2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805-2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805-2T1	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805-2T2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805-2T3	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805-2T4	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805OPT1	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805OPT2	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805OPT3	HUB OUTBOARD	BF GOODRICH	32-41-20
300-805OPT4	HUB OUTBOARD	BF GOODRICH	32-41-20
300-828	HUB OUTBOARD	BF GOODRICH	32-41-75
300-829	HUB INBOARD	BF GOODRICH	32-41-75
300-829-2	HUB INBOARD	BF GOODRICH	32-41-75
300-829-3	HUB INBOARD	BF GOODRICH	32-41-75
300-846-1OPT1	HUB INBOARD	BF GOODRICH	32-40-50
300-846-1OPT2	HUB INBOARD	BF GOODRICH	32-40-50
300-846-1OPT4	HUB INBOARD	BF GOODRICH	32-40-50
300-846OPT1	HUB INBOARD	BF GOODRICH	32-40-50
300-846OPT2	HUB INBOARD	BF GOODRICH	32-40-50
300-846OPT4	HUB INBOARD	BF GOODRICH	32-40-50
300-847OPT1	HUB OUTBOARD	BF GOODRICH	32-40-50
300-847OPT2	HUB OUTBOARD	BF GOODRICH	32-40-50
300-847OPT4	HUB OUTBOARD	BF GOODRICH	32-40-50
300-850	HUB INBOARD	BF GOODRICH	32-40-51
300-850OPT1	HUB INBOARD	BF GOODRICH	32-40-51
300-850OPT2	HUB INBOARD	BF GOODRICH	32-40-51
300-850OPT4	HUB INBOARD	BF GOODRICH	32-40-51
300-851	HUB OUTBOARD	BF GOODRICH	32-40-51
300-851OPT1	HUB OUTBOARD	BF GOODRICH	32-40-51
300-851OPT2	HUB OUTBOARD	BF GOODRICH	32-40-51
300-851OPT4	HUB OUTBOARD	BF GOODRICH	32-40-51
300-866	HUB OUTBOARD	BF GOODRICH	32-48-35
300-867	HUB INBOARD	BF GOODRICH	32-48-35
300-881 OPT1	HUB INBOARD	BF GOODRICH	32-40-54
300-881 OPT2	HUB INBOARD	BF GOODRICH	32-40-54
300-882 OPT1	HUB OUTBOARD	BF GOODRICH	32-40-54
300-882 OPT2	HUB OUTBOARD	BF GOODRICH	32-40-54
300-896	HUB INBOARD	BF GOODRICH	32-47-25
300-897	HUB OUTBOARD	BF GOODRICH	32-47-25
300-900OPT2	HUB INBOARD	BF GOODRICH	32-40-50

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
300-900OPT4	HUB INBOARD	BF GOODRICH	32-40-50
300-901-1	HUB OUTBOARD	BF GOODRICH	32-49-11
300-903	HUB OUTBOARD	BF GOODRICH	32-41-90
300-903OPT1	HUB OUTBOARD	BF GOODRICH	32-41-90
300-903OPT2	HUB OUTBOARD	BF GOODRICH	32-41-90
300-939	HUB INBOARD	BF GOODRICH	32-40-44
300-940	HUB OUTBOARD	BF GOODRICH	32-40-44
300-945	HUB OUTBOARD	BF GOODRICH	32-49-08
300-946	HUB INBOARD	BF GOODRICH	32-49-08
300-957	HUB INBOARD	BF GOODRICH	32-41-90
300-957-1	HUB INBOARD	BF GOODRICH	32-41-90
300-957-2	HUB INBOARD	BF GOODRICH	32-41-90
300-973	HUB INBOARD	BF GOODRICH	32-46-55
300-974	HUB OUTBOARD	BF GOODRICH	32-46-55
300-985	HUB INBOARD	BF GOODRICH	32-49-11
300-989OPT2	HUB INBOARD	BF GOODRICH	32-40-50
300-989OPT4	HUB INBOARD	BF GOODRICH	32-40-50
300-995	HUB OUTBOARD	BF GOODRICH	32-44-05
300-996	HUB INBOARD	BF GOODRICH	32-44-05
30-150	BRAKE UNIT	CLEVELAND	AWBPC0001
30-161	BRAKE UNIT	CLEVELAND	AWBPC0001
30-162	BRAKE UNIT	CLEVELAND	AWBPC0001
30-170	BRAKE UNIT	CLEVELAND	AWBPC0001
30-189	BRAKE UNIT	CLEVELAND	AWBPC0001
30-191	BRAKE UNIT	MEGGITT/ABS	32-42-58
30-23D	WHEEL BRAKE	CLEVELAND	AWBPC0001
30-242	BRAKE UNIT	CLEVELAND	CM30-242
304-330	HEATPACK	BF GOODRICH	32-40-62
304-332	HEATPACK	BF GOODRICH	32-40-61
304-334	HEATPACK	BF GOODRICH	32-40-63
30-93E	BRAKE UNIT	CLEVELAND	AWBCMM0001
3-1070	WHEEL NOSE	BF GOODRICH	32-40-01
310U2042-1	RETAINER		ASTM-E1417
310U2042-3	RETAINER		ASTM-E1417
3-1197	WHEEL NOSE	BF GOODRICH	3-1197 (266)
3-1208-1	WHEEL MAIN	BF GOODRICH	32-45-21
3-1209-2	WHEEL NOSE	BF GOODRICH	32-47-27
3-1306	WHEEL MAIN	BF GOODRICH	32-40-21
3-1306-1	WHEEL MAIN	BF GOODRICH	32-40-21
3-1306-1M	WHEEL MAIN	BF GOODRICH	32-40-21
3-1306M	WHEEL MAIN	BF GOODRICH	32-40-21
3-1311-3	WHEEL MAIN	BF GOODRICH	32-41-03
3-1341-1	WHEEL MAIN	BF GOODRICH	32-45-23
3-1357	WHEEL MAIN	BF GOODRICH	32-45-24
3-1357-1	WHEEL MAIN	BF GOODRICH	32-45-24
3-1365	WHEEL MAIN	BF GOODRICH	32-41-03
3-1365-1	WHEEL MAIN	BF GOODRICH	32-41-03
3-1365-2	WHEEL MAIN	BF GOODRICH	32-41-03
3-1372	WHEEL MAIN	BF GOODRICH	32-45-44
3-1372-1	WHEEL MAIN	BF GOODRICH	32-45-44
3-1375	WHEEL MAIN	BF GOODRICH	32-41-03
3-1375-1	WHEEL MAIN	BF GOODRICH	32-41-03
3-1375-2	WHEEL MAIN	BF GOODRICH	32-41-03
3-1375-3	WHEEL MAIN	BF GOODRICH	32-41-03
3-1414	WHEEL MAIN	BF GOODRICH	32-40-21
3-1418	WHEEL NOSE	BF GOODRICH	32-47-42
3-1418OPT1	WHEEL NOSE	BF GOODRICH	32-47-42
3-1418OPT2	WHEEL NOSE	BF GOODRICH	32-47-42

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
3-1418OPT3	WHEEL NOSE	BF GOODRICH	32-47-42
3-1418OPT4	WHEEL NOSE	BF GOODRICH	32-47-42
3-1422	WHEEL MAIN	BF GOODRICH	32-40-22
3-1423-1	WHEEL NOSE	BF GOODRICH	32-40-24
3-1423-2	WHEEL NOSE	BF GOODRICH	32-40-24
3-1423-3	WHEEL NOSE	BF GOODRICH	32-40-24
3-1426	WHEEL NOSE	BF GOODRICH	32-47-28
3-1427	WHEEL MAIN	BF GOODRICH	32-40-22
3-1428	WHEEL MAIN	BF GOODRICH	32-40-22
3-1435-2	WHEEL MAIN	BF GOODRICH	32-40-12
3-1435-3	WHEEL MAIN	BF GOODRICH	32-40-12
3-1435-4	WHEEL MAIN	BF GOODRICH	32-40-12
3-1438	WHEEL NOSE	BF GOODRICH	32-40-32
3-1438-1	WHEEL NOSE	BF GOODRICH	32-40-32
3-1439-5	WHEEL MAIN	BF GOODRICH	32-40-31
3-1439-6	WHEEL MAIN	BF GOODRICH	32-40-31
3-1442	WHEEL NOSE	BF GOODRICH	32-40-17
3-1446	WHEEL MAIN	BF GOODRICH	32-48-07
3-1448	WHEEL NOSE	BF GOODRICH	32-41-17
3-1470	WHEEL NOSE	HONEYWELL	32-41-12
3-1470-1	WHEEL NOSE	HONEYWELL	32-41-12
3-1471	WHEEL MAIN	BF GOODRICH	32-45-01
3-1471-1	WHEEL MAIN	BF GOODRICH	32-45-01
3-1471-2	WHEEL MAIN	BF GOODRICH	32-45-01
3-1479-1	WHEEL MAIN	BF GOODRICH	32-45-02
3-1479-2	WHEEL MAIN	BF GOODRICH	32-45-02
3-1480-1	WHEEL MAIN	BF GOODRICH	32-45-68
3-1480-2	WHEEL MAIN	BF GOODRICH	32-45-68
3-1481	WHEEL NOSE	BF GOODRICH	32-47-26
3-1484	WHEEL MAIN	BF GOODRICH	32-45-03
3-1485	WHEEL MAIN	BF GOODRICH	32-45-70
3-1490-1	WHEEL MAIN	BF GOODRICH	32-45-43
3-1491	WHEEL MAIN	BF GOODRICH	32-41-18
3-1509-2	WHEEL MAIN	BF GOODRICH	32-41-50
3-1509-3	WHEEL MAIN	BF GOODRICH	32-41-50
3-1510	WHEEL NOSE	BF GOODRICH	32-41-51
3-1510-1	WHEEL NOSE	BF GOODRICH	32-41-51
3-1518-1	WHEEL MAIN	BF GOODRICH	32-45-77
3-1518-2	WHEEL MAIN	BF GOODRICH	32-45-77
3-1527	WHEEL MAIN	BF GOODRICH	32-45-45
3-1527-1	WHEEL MAIN	BF GOODRICH	32-45-45
3-1527-2	WHEEL MAIN	BF GOODRICH	32-45-45
3-1528	WHEEL NOSE	BF GOODRICH	32-47-71
3-1530	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-1	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-1OPT2	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-1OPT3	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-2	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-3	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-4	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-4T2	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-4T3	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-4T4	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-5	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-5T2	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-5T3	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-5T4	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-6	WHEEL MAIN	BF GOODRICH	32-41-20

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
3-1530-6T2	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-6T3	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-6T4	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-7	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-7T2	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-7T3	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530-7T4	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530OPT2	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530OPT3	WHEEL MAIN	BF GOODRICH	32-41-20
3-1530OPT4	WHEEL MAIN	BF GOODRICH	32-41-20
3-1531	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-1	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-1OPT1	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-1OPT2	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-1OPT3	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-1OPT4	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-2	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-2OPT1	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-2OPT2	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-2OPT3	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-2OPT4	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-3	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-3OPT1	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-3OPT2	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-3OPT3	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531-3OPT4	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531OPT1	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531OPT2	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531OPT3	WHEEL NOSE	BF GOODRICH	32-41-13
3-1531OPT4	WHEEL NOSE	BF GOODRICH	32-41-13
3-1535	WHEEL NOSE	BF GOODRICH	32-40-41
3-1537	WHEEL MAIN	BF GOODRICH	
3-1538-1	WHEEL NOSE	BF GOODRICH	32-47-43
3-1540	WHEEL MAIN	BF GOODRICH	32-40-39
3-1544	WHEEL MAIN	BF GOODRICH	32-48-01
3-1545-1	WHEEL MAIN	BF GOODRICH	32-48-72
3-1546	WHEEL MAIN	BF GOODRICH	32-41-75
3-1547	WHEEL NOSE	BF GOODRICH	32-41-74
3-1550	WHEEL MAIN	BF GOODRICH	32-49-02
3-1550-1	WHEEL MAIN	BF GOODRICH	32-49-02
3-1551	WHEEL NOSE	BF GOODRICH	32-49-04
3-1557	WHEEL MAIN	BF GOODRICH	32-40-49
3-1558	WHEEL MAIN	BF GOODRICH	32-40-50
3-1558OPT1	WHEEL MAIN	BF GOODRICH	32-40-50
3-1558OPT2	WHEEL MAIN	BF GOODRICH	32-40-50
3-1558OPT4	WHEEL MAIN	BF GOODRICH	32-40-50
3-1559	WHEEL NOSE	BF GOODRICH	32-40-51
3-1562	WHEEL MAIN	BF GOODRICH	32-45-47
3-1571	WHEEL MAIN	BF GOODRICH	32-45-48
3-1571-1	WHEEL MAIN	BF GOODRICH	32-45-48
3-1571-2	WHEEL MAIN	BF GOODRICH	32-45-48
3-1571-3	WHEEL MAIN	BF GOODRICH	32-45-48
3-1571-4	WHEEL MAIN	BF GOODRICH	32-45-48
3-1571-5	WHEEL MAIN	BF GOODRICH	32-45-48
3-1571-6	WHEEL MAIN	BF GOODRICH	32-45-48
3-1573	WHEEL MAIN	BF GOODRICH	32-48-32
3-1573-1	WHEEL MAIN	BF GOODRICH	32-48-32
3-1574	WHEEL NOSE	BF GOODRICH	32-48-35

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
3-1575	WHEEL MAIN	BF GOODRICH	32-48-34
3-1576	WHEEL MAIN	BF GOODRICH	32-45-27
3-1581	WHEEL MAIN	BF GOODRICH	32-40-54
3-1581 OPT1	WHEEL MAIN	BF GOODRICH	32-40-54
3-1581 OPT2	WHEEL MAIN	BF GOODRICH	32-40-54
3-1586	WHEEL NOSE	BF GOODRICH	32-47-25
3-1596	WHEEL NOSE	BF GOODRICH	32-41-89
3-1599	WHEEL MAIN	BF GOODRICH	32-48-30
3-1601-2	WHEEL MAIN	BF GOODRICH	32-45-50
3-1601-3	WHEEL MAIN	BF GOODRICH	32-45-50
3-1607	WHEEL MAIN	BF GOODRICH	32-45-51
3-1607-1	WHEEL MAIN	BF GOODRICH	32-45-51
3-1618	WHEEL MAIN	BF GOODRICH	32-40-44
3-1619	WHEEL NOSE	BF GOODRICH	32-40-45
3-1621	WHEEL MAIN	BF GOODRICH	32-45-53
3-1622	WHEEL NOSE	BF GOODRICH	32-49-08
3-1628	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-1	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-1OPT1	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-1OPT2	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-2	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-2OPT1	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-2OPT2	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-2T1	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628-2T2	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628OPT1	WHEEL MAIN	BF GOODRICH	32-41-90
3-1628OPT2	WHEEL MAIN	BF GOODRICH	32-41-90
3-1631-1	WHEEL MAIN	BF GOODRICH	32-49-09
3-1640	WHEEL MAIN	BF GOODRICH	32-46-56
3-1641	WHEEL MAIN	BF GOODRICH	32-49-11
3-1642	WHEEL NOSE	BF GOODRICH	32-46-55
3-1650	WHEEL MAIN	BF GOODRICH	32-44-05
3-1650OPT1	WHEEL NOSE	BF GOODRICH	32-44-05
3-1650OPT2	WHEEL NOSE	BF GOODRICH	32-44-05
3-1654	WHEEL MAIN	BF GOODRICH	32-42-54
3-1661-2	WHEEL MAIN	BF GOODRICH	32-44-03
3-1661-2OPT1	WHEEL MAIN	BF GOODRICH	32-44-03
3-1661-2OPT2	WHEEL MAIN	BF GOODRICH	32-44-03
3-1664	WHEEL MAIN	BF GOODRICH	32-44-64
3-1666	WHEEL MAIN	BF GOODRICH	32-40-60
3-1670	WHEEL NOSE	BF GOODRICH	32-44-70
319-40	TUBE TORQUE	BF GOODRICH	32-41-87
319-41	TUBE TORQUE	BF GOODRICH	32-41-87
3499H2	UNDERCARRIAGE MAIN	FAIREY	32-10-02
3501H1	UNDERCARRIAGE NOSE	FAIREY	32-20-01
3501H2	UNDERCARRIAGE NOSE	FAIREY	32-20-01
3507H1	UNDERCARRIAGE MAIN	FAIREY	32-10-01
3811H1	UNDERCARRIAGE NOSE	FAIREY	32-20-01
3811H2	UNDERCARRIAGE NOSE	FAIREY	32-20-01
400SG1103-12	DRIVE SHAFT	AMS	ASTM-E-1444
400SG2203-12	DRIVE SHAFT	AMS	ASTM-E-1444
40-128E	WHEEL MAIN	CLEVELAND	AWBPC0001
40-130	WHEEL MAIN	CLEVELAND	AWBPC0001
40-140 SERIES	WHEEL NOSE	CLEVELAND	AWBPC0001
40-141	WHEEL MAIN	CLEVELAND	AWBPC0001
40-172	WHEEL MAIN	CLEVELAND	AWBPC0001
40-203	WHEEL MAIN	CLEVELAND	AWBPC0001
40-204	NOSE WHEEL	CLEVELAND	AWBPC0001

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
40-210	WHEEL NOSE	CLEVELAND	AWBPC0001
40-239	WHEEL MAIN	CLEVELAND	AWBPC0001
40-258	WHEEL MAIN	CLEVELAND	AWBPC0001
40-262AA	WHEEL NOSE	CLEVELAND	AWBPC0001
40-289	WHEEL MAIN	CLEVELAND	AWBPC0001
40-412	WHEEL MAIN	CLEVELAND	CM40-412
40-413	WHEEL NOSE	CLEVELAND	CM40-413
40-424	WHEEL MAIN	CLEVELAND	CM40-424
40-434	WHEEL MAIN	CLEVELAND	AWBPC0001
40-76D	WHEEL NOSE	CLEVELAND	AWBPC0001
40-90	WHEEL MAIN	CLEVELAND	AWBPC0001
4-365	TUBE TORQUE	BF GOODRICH	32-40-48
5000268-3	BRAKE UNIT	MEGGITT	32-43-03
5000306-4	WHEEL MAIN	MEGGITT	32-41-01
5000757	WHEEL MAIN	MEGGITT	32-41-02
5000757-1	WHEEL MAIN	MEGGITT	32-41-02
5000757-10	WHEEL MAIN	MEGGITT	32-41-02
5000757-2	WHEEL MAIN	MEGGITT	32-41-02
5000757-3	WHEEL MAIN	MEGGITT	32-41-02
5000757-4	WHEEL MAIN	MEGGITT	32-41-02
5000757-5	WHEEL MAIN	MEGGITT	32-41-02
5000757-6	WHEEL MAIN	MEGGITT	32-41-02
5000757-8	WHEEL MAIN	MEGGITT	32-41-02
5000757-9	WHEEL MAIN	MEGGITT	32-41-02
5000758-10	BRAKE UNIT	MEGGITT	32-43-02
5000758-10R	BRAKE UNIT	MEGGITT	32-43-02
5000784	INBOARD HUB	MEGGITT	32-41-02
5000916	INBOARD HUB	MEGGITT	ASTM-E-1417-M
5000917	OUTBOARD HUB	MEGGITT	ASTM-E-1417-M
5000919	WHEEL NOSE	MEGGITT	32-42-02
5000919-1	WHEEL NOSE	MEGGITT	32-42-02
5000919-2	WHEEL NOSE	MEGGITT	32-42-02
5001477-1	WHEEL MAIN	MEGGITT	32-40-66
5001477-2	WHEEL MAIN	MEGGITT	32-40-66
5001477-3	WHEEL MAIN	MEGGITT	32-40-66
5001482	HUB OUTBOARD	MEGGITT	32-40-66
5001657	HUB INBOARD	MEGGITT	32-41-02
5001657-1	HUB OUTBOARD	MEGGITT	32-41-02
5001657-2	HUB OUTBOARD	MEGGITT	32-41-02
5001658	HUB INBOARD	MEGGITT	32-41-02
5001658-1	HUB INBOARD	MEGGITT	32-41-02
5001832	HUB INBOARD	MEGGITT	32-40-66
5002016	HUB INBOARD	MEGGITT	ASTM-E-1417-M
5002017	HUB OUTBOARD	MEGGITT	ASTM-E-1417-M
5002017-1	HUB OUTBOARD	MEGGITT	ASTM-E-1417-M
5002223-1	INBOARD HUB	MEGGITT	32-41-02
5002223-2	INBOARD HUB	MEGGITT	32-41-02
5002223-3	INBOARD HUB	MEGGITT	32-41-02
5002256	BRAKE UNIT	MEGGITT	32-44-09
5002460	WHEEL MAIN	MEGGITT/ABS	32-40-47
5002460-1	WHEEL MAIN	MEGGITT/ABS	32-40-47
5002460-2	WHEEL MAIN	MEGGITT/ABS	32-40-47
5002461	HUB INBOARD	MEGGITT/ABS	32-40-47
5002461-1	HUB INBOARD	MEGGITT/ABS	32-40-47
5002461-2	HUB INBOARD	MEGGITT/ABS	32-40-47
5002464	HUB OUTBOARD	MEGGITT/ABS	32-40-47
5002464-1	HUB OUTBOARD	MEGGITT/ABS	32-40-47
5002464-2	HUB OUTBOARD	MEGGITT/ABS	32-40-47

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
5003065	BRAKE UNIT	MEGGITT	32-43-33
5003065-2	BRAKE UNIT	MEGGITT	32-43-33
5003066	HUB OUTBOARD	MEGGITT	32-40-66
5003086-1	BRAKE UNIT	MEGGITT	32-43-34
5003086-2	BRAKE UNIT	MEGGITT	32-43-34
5003086-3	BRAKE UNIT	MEGGITT	32-43-34
5003329	HUB INBOARD	MEGGITT	32-41-02
5003329-1	HUB INBOARD	MEGGITT	32-41-02
5003329-2	HUB INBOARD	MEGGITT	32-41-02
5003329-3	HUB INBOARD	MEGGITT	32-41-02
5003330	OUTBOARD HUB	MEGGITT	32-41-02
5003330-1	OUTBOARD HUB	MEGGITT	32-41-02
5003330-2	HUB OUTBOARD	MEGGITT	32-41-02
5003330-3	HUB OUTBOARD	MEGGITT	32-41-02
5003588	WHEEL MAIN	MEGGITT/ABS	32-40-57
5003706	NOSE WHEEL	MEGGITT	32-46-15
5004069	WHEEL MAIN	MEGGITT	32-40-56
5004070	BRAKE UNIT	MEGGITT	32-43-49
5004070-2	BRAKE UNIT	MEGGITT	32-43-49
5004236	BRAKE UNIT	MEGGITT	32-43-47
5004320-2	WHEEL MAIN	MEGGITT	32-40-60
5004320-3	WHEEL MAIN	MEGGITT	32-40-60
5004320-4	WHEEL MAIN	MEGGITT	32-40-60
5004320-5	WHEEL MAIN	MEGGITT	32-40-60
5004320-6	WHEEL MAIN	MEGGITT	32-40-60
5004320-7	WHEEL MAIN	MEGGITT	32-40-60
5004320-8	WHEEL MAIN	MEGGITT	32-40-60
5004321-10	BRAKE UNIT	MEGGITT	32-43-50
5004321-11	BRAKE UNIT	MEGGITT	32-43-50
5004321-12	BRAKE UNIT	MEGGITT	32-43-50
5004321-14	BRAKE UNIT	MEGGITT	32-43-50
5004321-6	BRAKE UNIT	MEGGITT	32-43-50
5004551	HUB INBOARD	MEGGITT	32-40-66
5006028-1	WHEEL MAIN	MEGGITT	Q82-01
5006028-2	WHEEL MAIN	MEGGITT	Q82-01
5006028-3	WHEEL MAIN	MEGGITT	Q82-01
5006028-4	WHEEL MAIN	MEGGITT	Q82-01
5006028-5	WHEEL MAIN	MEGGITT	Q82-01
5006087-1	HUB INBOARD	MEGGITT	Q82-01
5006087-2	HUB INBOARD	MEGGITT	Q82-01
5006087-3	HUB INBOARD	MEGGITT	Q82-01
5006088-1	HUB OUTBOARD	MEGGITT	Q82-01
5006088-2	HUB OUTBOARD	MEGGITT	Q82-01
5006088-3	HUB OUTBOARD	MEGGITT	Q82-01
5006227	WHEEL NOSE	MEGGITT	32-46-19
5006249	BRAKE UNIT	MEGGITT	32-43-60
5006249-2	BRAKE UNIT	MEGGITT	32-43-60
5006450	WHEEL NOSE	MEGGITT	32-46-12
5006450-1	WHEEL NOSE	MEGGITT	32-46-12
5006450-2	WHEEL NOSE	MEGGITT	32-46-12
5006450-3	WHEEL NOSE	MEGGITT	32-46-12
5006450-4	WHEEL NOSE	MEGGITT	32-46-12
5006450-5	WHEEL NOSE	MEGGITT	32-46-12
5006484	BRAKE UNIT	MEGGITT	32-43-47
5006488	HUB OUTBOARD	MEGGITT	32-46-19
5006490	HUB INBOARD	MEGGITT	32-46-19
5006528	WHEEL NOSE	MEGGITT	32-46-18
5006528-1	WHEEL NOSE	MEGGITT	32-46-18

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
5006618	WHEEL MAIN	MEGGITT	32-40-69
5006618-1	WHEEL MAIN	MEGGITT	32-40-69
5006618-2	WHEEL MAIN	MEGGITT	32-40-69
5006618-3	WHEEL MAIN	MEGGITT	32-40-69
5006618-4	WHEEL MAIN	MEGGITT	32-40-69
5006749	BRAKE UNIT	MEGGITT	Q82-02
5006749-2	BRAKE UNIT	MEGGITT	Q82-02
5006749-3	BRAKE UNIT	MEGGITT	Q82-02
5006749-4	BRAKE UNIT	MEGGITT	Q82-02
5006749-5	BRAKE UNIT	MEGGITT	32-44-66
5006749-5R	BRAKE UNIT	MEGGITT	32-44-66
5006856	WHEEL MAIN	MEGGITT	32-40-74
5006856-1	WHEEL MAIN	MEGGITT	32-40-74
5006856-2	WHEEL MAIN	MEGGITT	32-40-74
5006856-3	WHEEL MAIN	MEGGITT	32-40-74
5006856-4	WHEEL MAIN	MEGGITT	32-40-74
5006856-5	WHEEL MAIN	MEGGITT	32-40-74
5006856-5R	WHEEL MAIN	MEGGITT	32-40-74
5006857	BRAKE UNIT	MEGGITT	32-43-67
5006857-1	BRAKE UNIT	MEGGITT	32-43-67
5006857-2	BRAKE UNIT	MEGGITT	32-43-67
5006858-1	WHEEL NOSE	MEGGITT	32-46-21
5006858-2	WHEEL NOSE	MEGGITT	32-46-21
5006858-2A	WHEEL NOSE	MEGGITT	32-46-21
5006865-4	HUB INBOARD	MEGGITT	32-40-74
5006868-3	HUB OUTBOARD	MEGGITT	32-40-74
5007397	WHEEL MAIN	MEGGITT	32-40-82
5007397-1	WHEEL MAIN	MEGGITT	32-40-82
5007397-2	WHEEL MAIN	MEGGITT	32-40-82
5007553	WHEEL NOSE	MEGGITT	32-46-23
5007554-2	WHEEL MAIN	MEGGITT	32-40-78
5007679-2	HUB INBOARD	MEGGITT	32-40-78
5007681-2	HUB OUTBOARD	MEGGITT	32-40-78
5007707	HUB OUTBOARD	MEGGITT	32-46-23
500783	OUTBOARD HUB	MEGGITT	32-41-02
5007897-1	WHEEL MAIN	MEGGITT	32-40-79
5007897-2	WHEEL MAIN	MEGGITT	32-40-79
5007897-3	WHEEL MAIN	MEGGITT	32-40-79
5007898	BRAKE UNIT	MEGGITT	32-43-73
5007898-1	BRAKE UNIT	MEGGITT	32-43-73
5007898-2	BRAKE UNIT	MEGGITT	32-43-73
5007898-3	BRAKE UNIT	MEGGITT	32-43-73
5007995	WHEEL MAIN	MEGGITT	32-40-80
5007995-1	WHEEL MAIN	MEGGITT	32-40-80
5007996-1	BRAKE UNIT	MEGGITT	32-43-76
5007998	WHEEL NOSE	MEGGITT	32-46-24
5008133	WHEEL NOSE	MEGGITT	32-46-25
5008133-1	WHEEL NOSE	MEGGITT	32-46-25
5008309	WHEEL MAIN	MEGGITT	32-40-93
5008873	HUB INBOARD SUB-ASSY	MEGGITT	Q82-01
5008873-1	HUB INBOARD SUB-ASSY	MEGGITT	Q82-01
5008874	HUB OUTBOARD	MEGGITT	Q82-01
5009029	WHEEL MAIN	MEGGITT	32-40-94
5009029-1	WHEEL MAIN	MEGGITT	32-40-94
5009029R	WHEEL MAIN	MEGGITT	32-40-94
5009029R-1	WHEEL MAIN	MEGGITT	32-40-94
5009808	BRAKE HOUSING	MEGGITT	32-44-65
5009850-1	BRAKE UNIT	MEGGITT	32-43-87

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
5009850-2	BRAKE UNIT	MEGGITT	32-43-87
5009850-3	BRAKE UNIT	MEGGITT	32-43-87
5009850-4	BRAKE UNIT	BF GOODRICH	32-44-85
5009850-4	BRAKE UNIT	MEGGITT	32-43-87
5009904	BRAKE HOUSING	MEGGITT	32-44-65
5009904-1	BRAKE HOUSING	MEGGITT	32-44-65
5009904-2	HOUSING PISTON	MEGGITT	32-44-65
5009904-3	BRAKE HOUSING	MEGGITT	32-44-65
5009904-4	BRAKE HOUSING	MEGGITT	32-44-65
5009904-5	BRAKE HOUSING	MEGGITT	32-44-65
5009904-6	BRAKE HOUSING	MEGGITT	32-44-65
5009904-7	BRAKE HOUSING	MEGGITT	32-44-65
5009963	WHEEL MAIN	MEGGITT	32-40-95
5009963-2	WHEEL MAIN	MEGGITT	32-40-95
5010488	WHEEL MAIN	MEGGITT	32-41-16
5010488-1	WHEEL MAIN	MEGGITT	32-41-16
5010488-2	WHEEL MAIN	MEGGITT	32-41-16
5010488-3	WHEEL MAIN	MEGGITT	32-41-16
5010520-1	BRAKE UNIT	MEGGITT	32-43-96
5010571	WHEEL MAIN	MEGGITT	32-40-98
5010571-1	WHEEL MAIN	MEGGITT	32-40-98
5010598	WHEEL NOSE	MEGGITT/ABS	32-46-27
5010735	BRAKE UNIT	MEGGITT	32-44-61
5010735-1	BRAKE UNIT	MEGGITT	32-44-61
5010735-2	BRAKE UNIT	MEGGITT	32-44-61
5010735-3	BRAKE UNIT	MEGGITT	32-44-61
5010735-4	BRAKE UNIT	MEGGITT	32-44-61
5010735-7	BRAKE UNIT	MEGGITT	32-44-61
5010736	WHEEL MAIN	MEGGITT	32-41-21
5010736-1	WHEEL MAIN	MEGGITT	32-41-21
5010736-1W	WHEEL MAIN	MEGGITT	32-41-21
5010736-2	WHEEL MAIN	MEGGITT	32-41-21
5010736W	WHEEL MAIN	MEGGITT	32-41-21
5010737	WHEEL NOSE	MEGGITT	32-46-28
5010737-1	WHEEL NOSE	MEGGITT	32-46-28
5010737-2	WHEEL NOSE	MEGGITT	32-46-28
5010933-1	BRAKE UNIT	ABSC	32-43-93
5010933-2	BRAKE UNIT	ABSC	32-43-93
5010933-3	BRAKE UNIT	ABSC	32-43-93
5010933-4	BRAKE UNIT	ABSC	32-43-93
5011165-1	HUB INBOARD	MEGGITT	32-41-20
5011166	WHEEL MAIN	MEGGITT	32-41-20
5011169	HUB INBOARD	MEGGITT	32-41-02
5011529-1	WHEEL MAIN	MEGGITT	32-41-22
5011529-2	WHEEL MAIN	MEGGITT	32-41-22
5011529-3	WHEEL MAIN	MEGGITT	32-41-22
5011586-2	BRAKE UNIT	MEGGITT/ABS	32-44-64
5011586-3	BRAKE UNIT	MEGGITT/ABS	32-44-64
5011586-4	BRAKE UNIT	MEGGITT/ABS	32-44-64
5011640	BRAKE UNIT	MEGGITT	32-44-63
5011640-1	BRAKE UNIT	MEGGITT	32-44-63
5011640-2	BRAKE UNIT	MEGGITT	32-44-63
5011809	BRAKE UNIT	MEGGITT	32-44-65
5011809-1	BRAKE UNIT	MEGGITT	32-44-65
5011809-2	BRAKE UNIT	MEGGITT	32-44-65
5011809-3	BRAKE UNIT	MEGGITT	32-44-65
5012373	WHEEL MAIN	MEGGITT/ABS	32-42-28
5012589-3	BRAKE UNIT	MEGGITT	32-44-76

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
5012589-4	BRAKE UNIT	MEGGITT	32-44-76
5012609	BRAKE UNIT	MEGGITT	32-43-14
5013640	WHEEL NOSE	MEGGITT	32-46-30
5013642	BRAKE UNIT	MEGGITT	32-44-77
5013678	HOUSING	MEGGITT	32-45-12
5014197	WHEEL NOSE	MEGGITT	32-41-33
5014199-1	WHEEL NOSE	MEGGITT	32-46-36
5141053-7	WHEEL NOSE	CLEVELAND	AWBPC0001
537-52OPT1	HEATPACK	BF GOODRICH	
537-52OPT2	HEATPACK	BF GOODRICH	
537-52OPT3	HEATPACK	BF GOODRICH	
537-52OPT4	HEATPACK	BF GOODRICH	
59000075-001	HEATPACK	HONEYWELL	32-43-12
60P3242101A003	WHEEL MAIN	MEGGITT	32-41-47
6105-1	FUSE HYDRAULIC	HONEYWELL	32-42-06
6213-4	FUSE HYDRAULIC	PNEUDRAULICS	27-54-01
6213-5	FUSE HYDRAULIC	PNEUDRAULICS	27-54-01
6252	FUSE HYDRAULIC	PNEUDRAULICS	32-40-03
6257	FUSE HYDRAULIC	PNEUDRAULICS	32-40-04
6271-1	FUSE HYDRAULIC	PNEUDRAULICS	32-40-04
6272-1	FUSE HYDRAULIC	PNEUDRAULICS	32-40-05
6273-1	FUSE HYDRAULIC	PNEUDRAULICS	32-40-05
6273-5	FUSE HYDRAULIC	PNEUDRAULICS	32-40-05
7232200-511	WHEEL NOSE	MEGGITT	32-46-19
7232200-512	WHEEL NOSE	MEGGITT	32-46-19
7232400-523	WHEEL MAIN	MEGGITT	32-41-16
7232400-527	WHEEL MAIN	MEGGITT	32-41-16
7332200-512	WHEEL NOSE	MEGGITT	32-46-28
7332200-513	WHEEL NOSE	MEGGITT	32-46-28
7332200-514	WHEEL NOSE	MEGGITT	32-46-28
7332200-515	WHEEL NOSE	MEGGITT	32-46-28
7332400-511	WHEEL MAIN	MEGGITT	32-41-21
7332400-512	WHEEL MAIN	MEGGITT	32-41-21
7332400-513	WHEEL MAIN	MEGGITT	32-41-21
7332400-514	WHEEL MAIN	MEGGITT	32-41-21
7332400-515	WHEEL MAIN	MEGGITT	32-41-21
83769-14-17	BOLT	IAE	ASTM-E1417
83769-14-74	BOLT	IAE	ASTM-E1417
83769-16-14	BOLT	IAE	ASTM-E1417
83769H-14-17	BOLT	IAE	ASTM-E1417
83769-H14-17	BOLT	IAE	ASTM-E1417
83769H-14-74	BOLT	IAE	ASTM-E1417
83769-H14-74	BOLT	IAE	ASTM-E1417
83769H-16-14	BOLT	IAE	ASTM-E1417
83769-H16-14	BOLT	IAE	ASTM-E-1417-M
90000581	WHEEL NOSE	MEGGITT	32-49-19
90000581-1	WHEEL NOSE	MEGGITT	32-49-19
90000582	WHEEL MAIN	MEGGITT	32-49-21
90000582-1	WHEEL MAIN	MEGGITT	32-49-21
90000583-1	BRAKE UNIT	MEGGITT	32-49-23
90000583-1PR	BRAKE UNIT	MEGGITT	32-49-23
90000583-2	BRAKE UNIT	MEGGITT	32-49-23
90000583-2PR	BRAKE UNIT	MEGGITT	32-49-23
90000583-3	BRAKE UNIT	MEGGITT	32-49-23
90000583-3PR	BRAKE UNIT	MEGGITT	32-49-23
90000583-5	BRAKE UNIT	MEGGITT	32-49-23
90000583-5PR	BRAKE UNIT	MEGGITT	32-49-23
90000583-6	BRAKE UNIT	MEGGITT	32-49-23

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
90000583-6PR	BRAKE UNIT	MEGGITT	32-49-23
90001200-1	WHEEL MAIN	MEGGITT	32-41-32
90001201	BRAKE UNIT	MEGGITT	32-45-12
90001201-1	BRAKE UNIT	MEGGITT	32-45-12
90001301-1	HUB INBOARD	MEGGITT	32-41-32
90001320-1	HUB OUTBOARD	MEGGITT	32-41-32
90002024	WHEEL MAIN	MEGGITT	32-41-34
90002024-1	WHEEL MAIN	MEGGITT	32-41-34
90002025	HUB INBOARD	MEGGITT	32-41-34
90002029	HUB OUTBOARD	MEGGITT	32-41-34
90002030	BRAKE UNIT	MEGGITT	32-44-26
90002030-1	BRAKE UNIT	MEGGITT	32-44-26
90002317	WHEEL MAIN	MEGGITT	32-49-28
90002317-1	WHEEL MAIN	MEGGITT	32-49-28
90002317-2	WHEEL MAIN	MEGGITT	32-49-28
90002340	BRAKE UNIT	MEGGITT	32-49-30
90002340-1	BRAKE UNIT	MEGGITT	32-49-30
90002340-1PR	BRAKE UNIT	MEGGITT	32-49-30
90002340-2	BRAKE UNIT	MEGGITT	32-49-30
90002340-2PR	BRAKE UNIT	MEGGITT	32-49-30
90002340-4	BRAKE UNIT	MEGGITT	32-49-30
90002340-4PR	BRAKE UNIT	MEGGITT	32-49-30
90002340-5	BRAKE UNIT	MEGGITT	32-49-30
90002340-5PR	BRAKE UNIT	MEGGITT	32-49-30
90002340PR	BRAKE UNIT	MEGGITT	32-49-30
90002347	TORQUE TUBE & BACKPLATE	MEGGITT	ASTM-E-1444
90005024	WHEEL MAIN	MEGGITT	32-41-40
90005497	HOUSING	MEGGITT	32-44-94
90005497-1	HOUSING	MEGGITT	32-44-94
90005542	WHEEL MAIN	MEGGITT	32-41-44
90005543	BRAKE UNIT	MEGGITT	32-44-94
90005543P	BRAKE UNIT	MEGGITT	32-44-94
90005586-1	WHEEL MAIN	MEGGITT	32-41-47
90005587	WHEEL NOSE	MEGGITT	32-46-46
90005597	HOUSING	MEGGITT	32-44-94
90005597-1	HOUSING	MEGGITT	32-44-94
90005614	HUB INBOARD	MEGGITT	32-41-44
90005615	HUB OUTBOARD	MEGGITT	32-41-44
90006059	INBOARD HUB	MEGGITT	32-46-46
90006060	OUTBOARD HUB	MEGGITT	32-46-46
90006061	INBOARD HUB ASSY	MEGGITT	32-46-46
90006062	OUTBOARD HUB ASSY	MEGGITT	32-46-46
90010812	WHEEL MAIN	ABS	32-42-92
90-380038-1	BRAKE UNIT	BF GOODRICH	32-46-26
93479-16-26	BOLT		ASTM-E1417
9535864	HUB INBOARD	MEGGITT	32-41-45
9535864-1	HUB INBOARD	MEGGITT	32-41-45
9535865	OUTBOARD HUB	MEGGITT	32-41-45
9535865-1	HUB OUTBOARD	MEGGITT	32-41-45
9536598	HUB INBOARD	MEGGITT	32-46-14
9536598-10	HUB INBOARD	MEGGITT	32-46-14
9536598-7	HUB INBOARD	MEGGITT	32-46-14
9536598-8	HUB INBOARD	MEGGITT	32-46-14
9536599	HUB OUTBOARD	MEGGITT	32-46-14
9536599-10	HUB OUTBOARD	MEGGITT	32-46-14
9536599-7	HUB OUTBOARD	MEGGITT	32-46-14
9536599-8	HUB OUTBOARD	MEGGITT	32-46-14
9541493	WHEEL NOSE	MEGGITT	32-46-10

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
9541584	BRAKE UNIT	MEGGITT	32-43-43
9543426	WHEEL NOSE	MEGGITT	32-46-11
9543705	WHEEL NOSE	MEGGITT	32-46-08
9543705-1	WHEEL NOSE	MEGGITT	32-46-08
9543809	WHEEL MAIN	MEGGITT	32-41-45
9543809-1	WHEEL MAIN	MEGGITT	32-41-45
9544207	WHEEL NOSE	MEGGITT	32-46-14
9544207-2	WHEEL NOSE	MEGGITT	32-46-14
9544207-3	WHEEL NOSE	MEGGITT	32-46-14
9544207-4	WHEEL NOSE	MEGGITT	32-46-14
9544207-5	WHEEL NOSE	MEGGITT	32-46-14
9544207-6	WHEEL NOSE	MEGGITT	32-46-14
9544207-7	WHEEL NOSE	MEGGITT	32-46-14
9544382	WHEEL MAIN	MEGGITT	32-40-24
9544382-1	WHEEL MAIN	MEGGITT	32-40-24
9544382-2	WHEEL MAIN	MEGGITT	32-40-24
9550207-2	WHEEL MAIN	ABS	32-40-26
9550266	BRAKE UNIT	MEGGITT	32-40-30
9550267-2	WHEEL NOSE	MEGGITT	32-46-13
9550267-3	WHEEL NOSE	MEGGITT	32-46-13
9550267-5	WHEEL NOSE	MEGGITT	32-46-13
9550267-6	WHEEL NOSE	MEGGITT	32-46-13
9550267-6A	WHEEL NOSE	MEGGITT	32-46-13
9550267-8A	WHEEL NOSE	MEGGITT	32-46-13
9550377	BRAKE UNIT	MEGGITT	32-43-23
9550377-1	BRAKE UNIT	MEGGITT	32-43-23
9550377-2	BRAKE UNIT	MEGGITT	32-43-23
9550377-4	BRAKE UNIT	MEGGITT	32-43-23
9550463-2	WHEEL MAIN	MEGGITT	32-40-25
9550504	BRAKE UNIT	MEGGITT	32-40-07
9550661	BRAKE UNIT	MEGGITT	32-40-30
9560571B	WHEEL MAIN	ABS	32-40-01
9561062	BRAKE UNIT	MEGGITT	32-40-30
9912246-24	BRAKE UNIT	BF GOODRICH	32-46-42
9912246-25	BRAKE UNIT	BF GOODRICH	32-46-42
9912246-27	BRAKE UNIT	BF GOODRICH	32-46-42
9912469-5	BRAKE UNIT	BF GOODRICH	32-46-48
9912469-7	BRAKE UNIT	BF GOODRICH	32-46-48
9914069-2	WHEEL NOSE ASSY	BF GOODRICH	32-47-42
9914069-3	WHEEL NOSE ASSY	BF GOODRICH	32-47-42
9914069-4	WHEEL NOSE ASSY	BF GOODRICH	32-47-42
A33965-10	HOUSING	SAFRAN	32-47-61
A33965-12	HOUSING	SAFRAN	32-47-61
A33965-14	HOUSING	SAFRAN	32-47-61
A35779	HUB INBOARD	SAFRAN	32-49-51
A35780	OUTBOARD HUB	SAFRAN	32-49-51
A35977	HUB INBOARD	SAFRAN	32-48-20
A35978	HUB OUTBOARD	SAFRAN	32-48-20
A36828-4	TORQUE TUBE	BF GOODRICH	32-49-80
A37061	HOUSING	SAFRAN	32-49-80
A37062	HOUSING	SAFRAN	32-49-80
A37063	TORQUE TUBE	BF GOODRICH	32-49-80
A37076	TORQUE TUBE	BF GOODRICH	32-49-80
A37251	HUB INBOARD	SAFRAN	32-49-83
A37252	OUTBOARD HUB	SAFRAN	32-49-83
A37774	OUTBOARD HUB	SAFRAN	32-49-83
A37840	HOUSING	SAFRAN	32-49-80
AC67070	SENSOR, TEMP		32-44-11

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
AFL014-303-0	HINGE BOLT		V Spec 3013
AFL014-303-0	HINGE BOLT		V Spec 3013
AFL014-303-0	HINGE BOLT		V Spec 3013
AH088642	HUB INBOARD	MEGGITT	32-42-62
AH089101	HUB INBOARD	MEGGITT	32-42-82
AH089617	HUB INBOARD	MEGGITT	32-42-92
AH089618	HUB OUTBOARD	MEGGITT	32-42-92
AH089965	HUB INBOARD	MEGGITT	32-42-92
AH089966	HUB OUTBOARD	MEGGITT	32-42-92
AH090010	HUB OUTBOARD	MEGGITT	32-42-62
AH090968	HEATPACK	MEGGITT	32-44-44
AH090968 RP1428	HEATPACK	MEGGITT	32-44-44
AH090968 RP1429	HEATPACK	MEGGITT	32-44-44
AH090968 RP1443	HEATPACK	MEGGITT	32-44-44
AH091320	HUB INBOARD	MEGGITT	32-42-92
AH43984	TORQUE TUBE	MEGGITT	32-42-58
AH44042	HUB INBOARD	MEGGITT	32-42-82
AH44107	HUB INBOARD	MEGGITT	32-42-91
AH44108	HUB OUTBOARD	MEGGITT	32-42-91
AH44152	TORQUE TUBE	MEGGITT	32-42-58
AH44154	TORQUE TUBE	MEGGITT	32-42-58
AH50786	WHEEL NOSE	MEGGITT	DM1184
AH51123	WHEEL MAIN	MEGGITT	DM1184
AH51128	WHEEL MAIN	MEGGITT	DM1184
AH51129	WHEEL NOSE	MEGGITT	DM1184
AH51461	BRAKE UNIT	MEGGITT	DM1184
AH51502	BRAKE UNIT	MEGGITT	DM1184
AH51862	BRAKE UNIT	MEGGITT	DM1184
AH51900	BRAKE UNIT	MEGGITT	32-4(1)-9
AH51909	WHEEL MAIN	MEGGITT	32-40-2(4)
AH51940	WHEEL NOSE	MEGGITT	DM1184
AH52031	WHEEL NOSE	MEGGITT	DM1184
AH52075	WHEEL MAIN	MEGGITT	32-40-2(4)
AH52206	WHEEL MAIN	MEGGITT	32-40-2(4)
AH52216	BRAKE UNIT	MEGGITT	DM1184
AH52218	BRAKE UNIT	MEGGITT	DM1184
AH52220	BRAKE UNIT	MEGGITT	DM1184
AH52222	BRAKE UNIT	MEGGITT	DM1184
AH52228	WHEEL MAIN	MEGGITT	DM1184
AH52279	WHEEL MAIN	MEGGITT	DM1184
AH52286	WHEEL MAIN	MEGGITT	32-40-2(4)
AH52339	WHEEL NOSE	MEGGITT	32-44-49
AH52587	WHEEL MAIN	MEGGITT	32-40-2(22)
AH52588	BRAKE UNIT	MEGGITT	32-40-5(17)
AH52590	WHEEL NOSE	SAFRAN	32-44-53
AH52685	WHEEL MAIN	MEGGITT	DM1184
AH52688	WHEEL NOSE	SAFRAN	32-44-53
AH52689	WHEEL MAIN	MEGGITT	32-40-2(22)
AH52690	BRAKE UNIT	MEGGITT	32-40-5(17)
AH52742	WHEEL MAIN	MEGGITT	DM1184
AH52765	BRAKE UNIT	MEGGITT	32-4(1)-9
AH52786	WHEEL MAIN	MEGGITT	32-40-2(4)
AH52802	WHEEL MAIN	MEGGITT	DM1184
AH52946	WHEEL MAIN	MEGGITT	DM1184
AH53073	WHEEL MAIN	MEGGITT	32-40-2(22)
AH53166	BRAKE UNIT	MEGGITT	DM1184
AH53168	BRAKE UNIT	MEGGITT	DM1184
AH53352	WHEEL NOSE	MEGGITT	DM1184

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
AH53374	WHEEL NOSE	SAFRAN	32-44-53
AH53375	WHEEL NOSE	SAFRAN	32-44-53
AH53411	WHEEL MAIN	MEGGITT	DM1184
AH53421	BRAKE UNIT	MEGGITT	32-40-5(17)
AH54422	WHEEL NOSE	MEGGITT	32-42-78
AH54450	BRAKE UNIT	MEGGITT	32-42-89
AH54452	WHEEL NOSE	MEGGITT	32-42-91
AH54474	WHEEL NOSE	MEGGITT	32-42-91
AH55003	TORQUE TUBE	MEGGITT	32-42-58
AH55020	BRAKE UNIT	MEGGITT	32-40-5(17)
AH55068	TUBE TORQUE	MEGGITT	32-42-58
AHA1215	WHEEL MAIN	MEGGITT	DM1184
AHA1256	WHEEL MAIN	MEGGITT	32-42-12
AHA1258	WHEEL MAIN	MEGGITT	32-42-12
AHA1287	WHEEL MAIN	MEGGITT	32-40-92
AHA1290	WHEEL NOSE	MEGGITT	32-42-55
AHA1292	BRAKE UNIT	MEGGITT	32-41-71
AHA1343	WHEEL MAIN	MEGGITT	DM1184
AHA1349	WHEEL NOSE	MEGGITT/DUNLOP	32-42-17
AHA1381	WHEEL MAIN	MEGGITT	32-42-12
AHA1383	WHEEL MAIN	MEGGITT	32-42-12
AHA1412	BRAKE UNIT	MEGGITT	32-42-58
AHA1413	BRAKE UNIT	MEGGITT	32-42-58
AHA1480	WHEEL MAIN	MEGGITT	32-42-12
AHA1481	HUB INBOARD	MEGGITT	32-42-59
AHA1481-RP1386	HUB INBOARD	MEGGITT	32-42-59
AHA1481-RP1427	HUB INBOARD	MEGGITT	32-42-59
AHA1483	HUB OUTBOARD	MEGGITT	32-42-59
AHA1489	WHEEL MAIN	MEGGITT	32-42-59
AHA1490	WHEEL MAIN	MEGGITT	32-42-62
AHA1512	HUB OUTBOARD	MEGGITT	32-42-82
AHA1558	BRAKE UNIT	MEGGITT	32-42-58
AHA1559	BRAKE UNIT	MEGGITT	32-42-58
AHA1606	WHEEL MAIN	MEGGITT	32-40-92
AHA1612	BRAKE UNIT	MEGGITT	32-42-80
AHA1648	WHEEL MAIN	MEGGITT	32-42-82
AHA1653	BRAKE UNIT	MEGGITT	32-42-93
AHA1653-10	BRAKE UNIT	MEGGITT	32-42-93
AHA1653-9	BRAKE UNIT	MEGGITT	32-42-93
AHA1663	WHEEL MAIN	MEGGITT	32-42-85
AHA1752	WHEEL MAIN	MEGGITT	32-42-92
AHA1802	BRAKE UNIT	MEGGITT	32-41-71
AHA1814	WHEEL MAIN	MEGGITT	32-40-92
AHA1835	BRAKE UNIT	MEGGITT	32-43-24
AHA1884	BRAKE UNIT	MEGGITT	32-42-98
AHA1890	WHEEL MAIN	MEGGITT	32-42-92
AHA1897	BRAKE UNIT	MEGGITT	32-43-26
AHA1900	WHEEL MAIN	MEGGITT	32-42-62
AHA1925	WHEEL MAIN	MEGGITT	32-42-59
AHA2004	BRAKE UNIT	MEGGITT	32-42-80
AHA2013	HUB INBOARD	MEGGITT	32-42-59
AHA2013-1386	HUB OUTBOARD	MEGGITT	32-42-59
AHA2013-RP1427	HUB OUTBOARD	MEGGITT	32-42-59
AHA2014	HUB OUTBOARD	MEGGITT	32-42-59
AHA2114	WHEEL MAIN	MEGGITT	32-44-42
AHA2120	WHEEL MAIN	MEGGITT	32-42-85
AHA2122	WHEEL MAIN	MEGGITT	32-42-85
AHA2139	WHEEL MAIN	MEGGITT/ABS	32-49-23

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
AHA2141	WHEEL NOSE	MEGGITT	32-44-37
AHA2174	BRAKE UNIT	MEGGITT	32-44-44
AHA2175	BRAKE UNIT	MEGGITT	32-44-44
AHA2177	BRAKE UNIT	MEGGITT	32-44-44
AHA2178	BRAKE UNIT	MEGGITT	32-44-44
AHA2218	WHEEL MAIN	MEGGITT	32-44-48
AHA2261	WHEEL MAIN	MEGGITT	32-44-86
AHA2331	BRAKE UNIT	MEGGITT	32-45-14
AHA2331-2	BRAKE UNIT	MEGGITT	32-45-14
AHA2331-3	BRAKE UNIT	MEGGITT	32-45-14
AHA2331-4	BRAKE UNIT	MEGGITT	32-45-14
AHA2332	BRAKE UNIT	MEGGITT	32-45-14
AHA2332-2	BRAKE UNIT	MEGGITT	32-45-14
AHA2332-3	BRAKE UNIT	MEGGITT	32-45-14
AHA2332-4	BRAKE UNIT	MEGGITT	32-45-14
AHM10135	HUB ASSY	MEGGITT	32-44-42
AHM8434	BRAKE HOUSING	MEGGITT	32-45-14
AHM8435	HOUSING BRAKE	MEGGITT	32-45-14
AHM8593	HUB OUTBOARD	MEGGITT	32-42-82
AHO89965	HUB INBOARD	MEGGITT	32-42-92
AHO89966	HUB OUTBOARD	MEGGITT	32-42-92
AHO91320	HUB INBOARD	MEGGITT	32-42-92
AHO91321	HUB OUTBOARD	MEGGITT	32-42-92
AIR46200-1	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR46200-2	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR46200-3	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR46200-4	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR46200-5	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR46200-6	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR46202-1	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR46202-1	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR46202-2	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR46202-3	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR46202-4	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR48280-1	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR48280-2	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR48280-3	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR48280-4	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR48280-5	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR48280-6	UNDERCARRIAGE NOSE	APPH	32-10-1283
AIR48934-1	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-10	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-11	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-2	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-3	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-4	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-5	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-6	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-7	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-8	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48934-9	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-10	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-2	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-3	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-4	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-5	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-6	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-7	UNDERCARRIAGE MAIN	APPH	32-10-1283

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
AIR48958-8	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR48958-9	UNDERCARRIAGE MAIN	APPH	32-10-1283
AIR83002-2	UNDERCARRIAGE MAIN	APPH	32-10-1283
C20147000	WHEEL MAIN	SAFRAN	32-49-16
C20147200	WHEEL MAIN	SAFRAN	32-49-16
C20194500-1	BRAKE UNIT	SAFRAN	32-46-66
C20194500-2	BRAKE UNIT	SAFRAN	32-46-66
C20194500-3	BRAKE UNIT	SAFRAN	32-46-66
C20194500-4	BRAKE UNIT	SAFRAN	32-46-66
C20194500-5	BRAKE UNIT	SAFRAN	32-46-66
C20194500-6	BRAKE UNIT	SAFRAN	32-46-66
C20194500-7	BRAKE UNIT	SAFRAN	32-46-66
C20194500-8	BRAKE UNIT	SAFRAN	32-46-66
C20194500-9	BRAKE UNIT	SAFRAN	32-46-66
C20195000	WHEEL MAIN	SAFRAN	32-46-38
C20195000-1	WHEEL MAIN	SAFRAN	32-46-38
C20195000-2	WHEEL MAIN	SAFRAN	32-46-38
C20195000-3	WHEEL MAIN	SAFRAN	32-46-38
C20195000-4	WHEEL MAIN	SAFRAN	32-46-38
C20195000-5	WHEEL MAIN	SAFRAN	32-46-38
C20195000-6	WHEEL MAIN	SAFRAN	32-46-38
C20195000-7	WHEEL MAIN	SAFRAN	32-46-38
C20195002	WHEEL MAIN	SAFRAN	32-47-19
C20195002-1	WHEEL MAIN	SAFRAN	32-47-19
C20195002-2	WHEEL MAIN	SAFRAN	32-47-19
C20195002-3	WHEEL MAIN	SAFRAN	32-47-19
C20195002-4	WHEEL MAIN	SAFRAN	32-47-19
C20195150	WHEEL MAIN	SAFRAN	32-46-63
C20195150-1	WHEEL MAIN	SAFRAN	32-46-63
C20195150-2	WHEEL MAIN	SAFRAN	32-46-63
C20195150-3	WHEEL MAIN	SAFRAN	32-46-63
C20195150-4	WHEEL MAIN	SAFRAN	32-46-63
C20195150-5	WHEEL MAIN	SAFRAN	32-46-63
C20195151	WHEEL MAIN	SAFRAN	32-46-63
C20195151-1	WHEEL MAIN	SAFRAN	32-46-63
C20195151-2	WHEEL MAIN	SAFRAN	32-46-63
C20195151-3	WHEEL MAIN	SAFRAN	32-46-63
C20195151-4	WHEEL MAIN	SAFRAN	32-46-63
C20195151-5	WHEEL MAIN	SAFRAN	32-46-63
C20195152	WHEEL MAIN	SAFRAN	32-47-19
C20195152-1	WHEEL MAIN	SAFRAN	32-47-19
C20195152-2	WHEEL MAIN	SAFRAN	32-47-19
C20195152-3	WHEEL MAIN	SAFRAN	32-47-19
C20195152-4	WHEEL MAIN	SAFRAN	32-47-19
C20195152-5	WHEEL MAIN	SAFRAN	32-47-19
C20195160	WHEEL MAIN	SAFRAN	32-46-67
C20195161	WHEEL MAIN	SAFRAN	32-46-67
C20195162	WHEEL MAIN	SAFRAN	32-47-46
C20205160	HUB INBOARD	SAFRAN	32-46-67
C20206160	HUB OUTBOARD	SAFRAN	32-46-67
C20210500-1	BRAKE UNIT	SAFRAN	32-44-68
C20210500-2	BRAKE UNIT	SAFRAN	32-44-68
C20210500-3	BRAKE UNIT	SAFRAN	32-44-68
C20210500-4	BRAKE UNIT	SAFRAN	32-44-68
C20210500-5	BRAKE UNIT	SAFRAN	32-44-68
C20210500-6	BRAKE UNIT	SAFRAN	32-44-68
C20210500-7	BRAKE UNIT	SAFRAN	32-44-68
C20210500-8	BRAKE UNIT	SAFRAN	32-44-68

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
C20210500-9	BRAKE UNIT	SAFRAN	32-44-68
C20210601	BRAKE UNIT	SAFRAN	32-44-69
C20210602	BRAKE UNIT	SAFRAN	32-44-69
C20210603	BRAKE UNIT	SAFRAN	32-44-69
C20210604	BRAKE UNIT	SAFRAN	32-44-69
C20210605	BRAKE UNIT	SAFRAN	32-44-69
C20210606	BRAKE UNIT	SAFRAN	32-44-69
C20210607	BRAKE UNIT	SAFRAN	32-44-69
C20210610	BRAKE UNIT	SAFRAN	32-44-69
C20211100	WHEEL MAIN	SAFRAN	32-44-53
C20211100-1	WHEEL MAIN	SAFRAN	32-44-53
C20211100-2	WHEEL MAIN	SAFRAN	32-44-53
C20211100-3	WHEEL MAIN	SAFRAN	32-44-53
C20211101	WHEEL MAIN	SAFRAN	32-44-53
C20211101-1	WHEEL MAIN	SAFRAN	32-44-53
C20211101-2	WHEEL MAIN	SAFRAN	32-44-53
C20211101-3	WHEEL MAIN	SAFRAN	32-44-53
C20211150	WHEEL MAIN	SAFRAN	32-44-54
C20211150-1	WHEEL MAIN	SAFRAN	32-44-54
C20211150-2	WHEEL MAIN	SAFRAN	32-44-54
C20211150-3	WHEEL MAIN	SAFRAN	32-44-54
C20211151	WHEEL MAIN	SAFRAN	32-44-54
C20211151-1	WHEEL MAIN	SAFRAN	32-44-54
C20211151-2	WHEEL MAIN	SAFRAN	32-44-54
C20211151-3	WHEEL MAIN	SAFRAN	32-44-54
C20211160	WHEEL MAIN	SAFRAN	32-44-54
C20211161	WHEEL MAIN	SAFRAN	32-44-54
C20211170	WHEEL MAIN	SAFRAN	32-44-94
C20220150	HUB OUTBOARD	SAFRAN	32-44-54
C20220150-1	HUB OUTBOARD	SAFRAN	32-44-54
C20225301	BRAKE UNIT	SAFRAN	32-47-49
C20225301-1	BRAKE UNIT	SAFRAN	32-47-49
C20225301-1AMDTA	BRAKE UNIT	SAFRAN	32-47-49
C20225301-1AMDTB	BRAKE UNIT	SAFRAN	32-47-49
C20225301-1AMDTC	BRAKE UNIT	SAFRAN	32-47-49
C20225301-1AMDTD	BRAKE UNIT	SAFRAN	32-47-49
C20225301AMDTA	BRAKE UNIT	SAFRAN	32-47-49
C20225301AMDTB	BRAKE UNIT	SAFRAN	32-47-49
C20225301AMDTC	BRAKE UNIT	SAFRAN	32-47-49
C20225301AMDTD	BRAKE UNIT	SAFRAN	32-47-49
C20225310	BRAKE UNIT	SAFRAN	32-47-50
C20225310 -1	BRAKE UNIT	SAFRAN	32-47-50
C20225410	BRAKE UNIT	SAFRAN	32-47-59
C20225410-1	BRAKE UNIT	SAFRAN	32-47-59
C20225508	BRAKE UNIT	SAFRAN	32-47-61
C20225509	BRAKE UNIT	SAFRAN	32-47-61
C20225510	BRAKE UNIT	SAFRAN	32-47-61
C20229000	THERMOCOUPLE	SAFRAN	32-47-21
C20229001	THERMOCOUPLE	SAFRAN	32-47-21
C20252000	WHEEL MAIN	SAFRAN	32-47-33
C20384100	WHEEL MAIN	SAFRAN	32-45-90
C20384110	WHEEL MAIN	SAFRAN	32-45-90
C20384200	WHEEL MAIN	SAFRAN	32-45-90
C20449000	BRAKE UNIT	BF GOODRICH	32-41-65
C20466000-1	HUB OUTBOARD	BF GOODRICH	32-42-15
C20466000-2	HUB OUTBOARD	BF GOODRICH	32-42-15
C20500000	WHEEL MAIN	BF GOODRICH	32-41-83
C20500100	WHEEL MAIN	BF GOODRICH	32-42-15

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
C20501100	HUB INBOARD	BF GOODRICH	32-42-15
C20501100-1	HUB INBOARD	BF GOODRICH	32-42-15
C20508000	BRAKE UNIT	SAFRAN	32-49-50
C20508000AMDTA	BRAKE UNIT	SAFRAN	32-49-50
C20508000AMDTB	BRAKE UNIT	SAFRAN	32-49-50
C20509000	WHEEL MAIN	SAFRAN	32-49-51
C20516000	HUB INBOARD	SAFRAN	32-49-51
C20517000	HUB OUTBOARD	SAFRAN	32-49-51
C20525000	WHEEL NOSE	SAFRAN	32-48-20
C20534000-1	BRAKE UNIT	BF GOODRICH	32-41-65
C20534050	BRAKE UNIT	BF GOODRICH	32-41-05
C20534100	BRAKE UNIT	BF GOODRICH	32-41-05
C20545000	WHEEL MAIN	SAFRAN	32-45-92
C20545100	WHEEL MAIN	SAFRAN	32-45-92
C205625000	WHEEL NOSE	SAFRAN	32-48-20
C20585710	BRAKE UNIT	SAFRAN	32-49-44
C20585711	BRAKE UNIT	SAFRAN	32-49-44
C20585712	BRAKE UNIT	SAFRAN	32-49-44
C20586100	WHEEL MAIN	SAFRAN	32-49-42
C20586101	WHEEL MAIN	SAFRAN	32-49-42
C20586110	WHEEL MAIN	SAFRAN	32-49-42
C20586120	WHEEL MAIN	SAFRAN	32-49-42
C20589000	WHEEL NOSE	SAFRAN	32-49-43
C20626000	WHEEL MAIN	SAFRAN	32-49-81
C20626200	WHEEL MAIN	SAFRAN	32-49-83
C20633000	BRAKE UNIT	BF GOODRICH	32-49-80
C20633000AMDTA	BRAKE UNIT	BF GOODRICH	32-49-80
C20633000AMDTB	BRAKE UNIT	BF GOODRICH	32-49-80
C20633000AMDTC	BRAKE UNIT	BF GOODRICH	32-49-80
C20637000	WHEEL NOSE	MEGGITT	32-49-82
C20640200	HUB INBOARD	SAFRAN	32-49-83
C20641200	OUTBOARD HUB	SAFRAN	32-49-83
C20641210	HUB OUTBOARD	SAFRAN	32-49-83
C21928	WHEEL NOSE	HONEYWELL	32-41-12
C21928-1	WHEEL NOSE	HONEYWELL	32-41-12
C2611202-2	BRAKE UNIT	HONEYWELL	32-47-04
DAA05270-01	HUB ASSY	MEGGITT	32-44-42
DAP00076-01	WHEEL NOSE	MEGGITT	32-45-86
DAP00077-01	WHEEL NOSE	MEGGITT	32-45-86
GA30446	TORQUE TUBE	SAFRAN	32-47-49
GA30724	TORQUE TUBE	SAFRAN	32-47-61
GA30728	TORQUE TUBE	SAFRAN	32-47-61
GA31262	HOUSING	SAFRAN	32-47-49
GA31262-1	HOUSING	SAFRAN	32-47-49
GA31262-2	HOUSING	SAFRAN	32-47-49
GA31262-3	HOUSING	SAFRAN	32-47-49
GA31270	HEATPACK	SAFRAN	32-47-49
GA31487-1	HOUSING PISTON	SAFRAN	32-49-50
GA31561	LIFE EXTENSION SHIM	SAFRAN	32-47-61
GA31596	HUB INBOARD ASSY	SAFRAN	32-48-20
GA31597	HUB INBOARD ASSY	SAFRAN	32-48-20
GA31598	HUB OUTBOARD ASSY	SAFRAN	32-48-20
GA31599	HUB OUTBOARD ASSY	SAFRAN	32-48-20
GA31716R1	HEATPACK	SAFRAN	32-46-66
GA31875-1	HOUSING	SAFRAN	32-49-44
GA31879	HUB INBOARD	SAFRAN	32-49-43
GA31880	HUB OUTBOARD	SAFRAN	32-49-43
GA32275	OUTBOARD HUB	SAFRAN	32-49-83

Capability List

PART NUMBER	DESCRIPTION	OEM	ATA
GA32275-1	OUTBOARD HUB	SAFRAN	32-49-83
GA32565	HUB OUTBOARD	SAFRAN	32-49-83
S160N030-330	WHEEL MAIN	BF GOODRICH	32-40-54
S168U400-330	WHEEL NOSE	BF GOODRICH	32-44-70
S272U860-5	FUSE HYDRAULIC	TRIUMPH	27-32-02
S272U860-7	FUSE HYDRAULIC	TRIUMPH	27-32-03
S273N203-4	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-1	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-11	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-12	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-13	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-15	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-16	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-2	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-3	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-5	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S274A100-6	FUSE HYDRAULIC	PNEUDRAULICS	32-31-04
S277A016-510	BRAKE UNIT	BF GOODRICH	32-49-80
S294W511-310	BRAKE UNIT	BF GOODRICH	32-40-43
S294W512-380	WHEEL MAIN	BF GOODRICH	32-40-44
VA340-25	MOUNT BOLT KIT	VIRGIN	CRS/71/011
VA340-600-22	MOUNT BOLT KIT	VIRGIN	CRS/71/012
VA747-400-17	MOUNT BOLT KIT	VIRGIN	2069